

Ultra High Pressure Valve Assemblies

Type HP-60 (60,000 PSI), Type HP-40 (40,000 PSI),
and HP-30 (30,000 PSI)



Shown with optional stainless steel actuator

CONTENTS

Overview.5

Component Descriptions5

 Body/Bonnet Assembly.5

 Innervalue5

 Actuator5

 Packing5

Unpacking & Inspection5

Installation.6

Reorienting the Air Connections.6

Operation7

 Adjusting the Closed Position.7

 Adjustment for Hydro Testing 60,000 PSI Valves with High Pressure/PFA Packing7

Hydro Test Procedure / Packing Adjustment8

Packing Replacement and/or Innervalue Replacement.9

HP-60 Ultra High Pressure Valve Assembly (60,000 PSI).10

HP-40 Ultra High Pressure Valve Assembly (40,000 PSI).11

HP-30 Ultra High Pressure Valve Assembly (30,000 PSI).12

OVERVIEW

This manual provides installation, operation and maintenance information relating to the HP-30, HP-40 and HP-60 valve assemblies.

For operator safety and optimum performance, these instructions should be read, understood and followed. All technical bulletins, drawings and literature pertaining to this design should be used with this manual.

COMPONENT DESCRIPTIONS

Body/Bonnet Assembly

- The lower portion of the unit is fitted into the pipeline.
- The body is a one-piece design containing the innervalue and packing set.
- The body is made of 316 barstock (HP30), tri-axially forged 316 SST (HP40) or 17-4PH H1150 SST (HP60)

Innervalue

- The needle (plug) and seat inside the body/bonnet assembly is the component which modulates the flow through the valve as the actuator strokes.

NOTE: The needle and seat are matched sets and should not be interchanged with other similar components, regardless of labeling.

- The innervalue is made of wrought Stellite 6B (stem and plug with 416 SST upper adapter). If these components are gold in color, they have been coated with titanium nitride.

Actuator

- The actuator sits atop the body/bonnet assembly and is connected to the body using a yoke locknut. The actuator may be either Air-To-Open (ATO) Spring-To-Close or Air-To-Close (ATC) Spring-To-Open.
- An ATO actuator closes the valve upon a decreasing instrument signal or loss of signal. The ATC actuator opens the valve upon a decreasing instrument signal, loss of signal or loss of air supply.

Packing

- The packing, a series of plastic rings, seals the stem of the valve, precluding leakage of the process media outside the valve. The materials and orientation of the rings can vary from valve to valve.
- Refer to your customer drawing for orientation and material type.

WARNING

VALVES OF THIS TYPE ARE TYPICALLY SUPPLIED WITH SOME FORM OF HIGH-PRESSURE PROCESS CONNECTION. BE SURE TO USE PROPER MATING FITTINGS TO CONNECT THE VALVE TO PROCESS LINES. USING MISMATCHED FITTINGS MAY RESULT IN DAMAGE TO THE BODY, LEAKAGE OR INJURY TO PERSONNEL.

UNPACKING & INSPECTION

Upon opening the shipping container, visually inspect the product and applicable accessories for any physical damage such as scratches, loose or broken parts, or any other sign of damage that may have occurred during shipment.

NOTE: If damage is found, request an inspection by the carrier's agent within 48 hours of delivery and file a claim with the carrier. A claim for equipment damage in transit is the sole responsibility of the purchaser.

INSTALLATION

NOTE: In the following sections, the numbers in parenthesis refer to the item numbers on the drawings on [page 10](#), [page 11](#) and [page 12](#).

1. For maintenance and servicing ease, the location selected for the valve assembly installation should allow for safe access to both sides of the valve.
2. Remove any protective plugs or devices from the valve body, stem, positioner lever, and so on.
3. Do not remove the black hex pipe plug vent from the actuator housing, so to prevent debris from entering the spring side of the housing during operation.
4. Make sure all lines are free of debris by flushing with fluid or blowing with clean air or other suitable gas, before connecting any lines.
5. Suitable isolation valves should be installed upstream and downstream of the control valve.
6. Due the small size and close clearances of the innervalue, proper filtration of the process is recommended. If unsure about filter size, contact the factory with the valves serial number and innervalue size.
7. Install the valve in the pipeline using mating fittings. Never mix fitting types or brands without prior knowledge or experience.
8. If the unit is not equipped with a positioner, connect the instrument signal line to the connector located inside the actuator housing:
 - Lower port if Air-To-Open.
 - Upper port if Air-To-Close.
9. If the unit is equipped with a positioner or other devices, make those connections according to the instructions for the device.

⚠CAUTION

DO NOT EXCEED AIR PRESSURE LIMITS.

- **90 PSIG FOR THE ACTUATOR (40...60 PSIG SHOULD BE SUFFICIENT FOR MOST APPLICATIONS).**
- **SEE SPECIFIC ACCESSORY MANUAL FOR OTHER DEVICES.**

IF THE UNIT IS EQUIPPED WITH A POSITIONER (I/P TRANSDUCER, REGULATOR), IT HAS BEEN PRE-ADJUSTED AT THE FACTORY. DO NOT ATTEMPT TO READJUST WITHOUT FIRST TESTING THE UNIT WITH THE PRESET SETTINGS.

REORIENTING THE AIR CONNECTIONS

Use the following procedure if the air connections must be reoriented and if the unit is an Air-To-Close (ATC) version:

1. Loosen the yoke lock nut (37) until the actuator can turn. Orient the unit as desired and retighten the yoke locknut.
2. If the unit is an Air-To-Open (ATO) version and must be reoriented. DO NOT simply rotate the actuator or damage the innervalue (43) may occur.
3. Connect the control air and/or electrical signal lines to the I/P or positioner, so the valve can be stroked.
4. Signal the valve to raise the innervalue off the seat 10...30%.
5. Once the innervalue is off the seat, loosen the yoke locknut and orient the actuator as desired.
6. Retighten the yoke locknut.
7. De-stroke the valve, lowering the innervalue to the seated position.
8. If the unit is equipped with a positioner or other accessories, refer to its instruction for operation and adjustment.
9. Use a paste type sealant or clear grease for air connections. DO NOT use TFE tape, as small pieces of the tape may block the small orifices in the devices. .
10. When stroking the valve, DO NOT remove the airline or electrical signal, as the unit to close rapidly, possibly damaging the innervalue.

NOTES:

- Although the valve will operate in any orientation, the vertical position is preferred for ease of maintenance and adjustment.
- Proper bracing and support is recommended, due to the weight of the unit.
- Brackets may be factory ordered or fabricated and attached to one or more of the actuator rim screws.

OPERATION

Before subjecting the valve to process conditions, verify:

- The stroke function of the unit, to make sure the valve is stroking properly in response to the instrument signal.
- All accessories are functioning properly.

If the unit is ATO upon an increasing input signal, the valve will stroke and increase the flow through the pipeline. If the unit is ATC, the valve will stroke and decrease the flow through the pipeline.

Adjusting the Closed Position

When in the closed position, the innervalue should achieve some level of shut-off, depending on innervalue size and required tightness. Typically, linear innervalves sizes K-O should achieve ANSI Class IV and P sizes should achieve Class III.

The actuator is equipped with either three or six springs. During assembly of the actuator, a specific level of preload is installed into the springs to achieve seating force on the innervalue. This preload is accomplished through the addition of bushings of a specific thickness atop each spring.

NOTE: Notice the two, long, hex “jack” screws and nuts across from each other at the actuator rim. As the springs are preloaded, see the section on actuator disassembly, prior to loosening the jack screws.

Seat tightness is pre-adjusted at the factory; however, due to wear or repeated changing of the innervalue, seat tightness may need to be adjusted.

To adjust the seating position or to achieve maximum tightness, use the following method:

NOTE: Application of excess closing force can bend or damage the innervalue/stem, due to high potential actuator force.

1. By signaling the actuator, stroke the valve to approximately 10% off the seat.
2. Place a wrench on the stem flats (7) and loosen the jam nut (27).
3. Using a wrench on the stem connector (13), loosen the connection. Do not loosen (29).
4. Turn the stem adjuster clockwise, threading the adjuster up into the actuator stem, three or four turns.
5. Using the input signal, close the valve by decreasing (ATO) or increasing (ATC) the signal.
6. The valve should be adjusted to seat the innervalue at:
 - Pneumatic Signal: 3.2 psi, if ATO and 14.9 psi if ATC.
 - Electric Signal: 4.1 mA if ATO and 19.9 mA if ATC.
7. Once the signal is set, turn the stem connector counterclockwise until the innervalue makes contact with the seat. DO NOT over-torque this adjustment or the seat may be damaged.
8. Holding the stem with a wrench, tighten the jam nut (27).
9. Reduce the signal to the minimum and conduct seat leak testing.

If leakage through the valve is excessive:

- Make sure the positioner is adjusted properly, causing the valve to be seated at the proper actuator signal.
- Replace the innervalue.

Adjustment for Hydro Testing 60,000 PSI Valves with High Pressure/PFA Packing

NOTE: These specifications may also be used for 40,000 psi-rated valves, provided hydro pressures do not exceed 60,000 psi.

Customer pressures for 40 KSI valves should not exceed 40,000 psi. Factory hydro pressure should not exceed 60,000 psi.

Customer pressures for 60 KSI valves should not exceed 60,000 psi, or 90,000 psi for factory hydro.

NOTE: Packing material and quantity of rings vary between the 40 and 60 KSI valves.

HYDRO TEST PROCEDURE / PACKING ADJUSTMENT

1. Plug the outlet of test valve and connect the inlet to the hydro pump.
2. Stroke test valve to 20-50% open.
3. Open upstream valve, under low pressure (60...100 psi) to vent air until water leaks past the packing. If the packing does not leak, slowly raise the pressure until water does leak.
4. Loosen the downstream plug until air is vented, then tighten.
5. Tighten packing gland (35) until water leakage stops.
6. Tighten the packing gland 1/16 inch turn past this point.
7. Slowly engage high pressure pump, stopping at 10,000 psi or whenever leakage occurs.
8. When leakage occurs or each increment is reached, reduce pressure to zero.

CAUTION

NEVER TIGHTEN THE PACKING GLAND WHILE THE VALVE IS UNDER PRESSURES HIGHER THAN 500 PSI, AS DAMAGE (GALL OR SEIZE) MAY OCCUR TO THE THREADS OF THE PACKING GLAND OR BODY.

9. Tighten the packing gland 1/16 inch turn.
10. Engage the high-pressure pump, stopping at the next 10,000 psi increment, or whenever leakage occurs.
11. Reduce test pressure to zero each time leakage occurs.
12. Tighten the packing gland approximately 1/16 inch turn.
13. Engage the high-pressure pump, stopping at the next 10,000 psi increment or whenever leakage occurs.
14. Reduce pressure to zero.
15. Tighten packing gland approximately 1/16 inch turn.

When the packing holds at 50,000 psi, the packing should hold between 60 KSI (for customer testing) or 90 KSI (for factory testing). If the packing does not hold, repeat the above steps 9 through 12 until all leakage is stopped.

IMPORTANT

- Sealing extremely high pressures is difficult at best.
- Although Teflon PFA is more resistant to cold flow (creep) than pure TFE, it is a plastic and possesses some cold flow.
- In addition to the forces applied to the packing by the gland, the system pressure also plays a part in sealing the packing against the stem and the packing cavity wall.
- Some packing relaxation is not uncommon. Therefore, the packing should be tested when the valve is installed.
- The pressure should be raised carefully and in stages to check for leaks.
- If leaks occur, the pressure should be lowered to zero, the gland turned clockwise 1/16 inch turn, then retested.
- Do not attempt to tighten the gland while the valve is under high pressure.
- When packing has been used for any length of time at super pressures and then reduced to lower pressures, the packing may leak when the pressure is then raised to higher pressures. If leakage occurs, some retightening may be necessary.
- If the valve is disassembled, always install new packing.
- Never reuse packing that has been removed from a used valve.
- If hydro-test is required to 90,000 psi, this high pressure will compress the packing to a point that it may not seal at 60,000 psi. After a 90,000 psi hydro-test is complete, replace with new packing, then test/tighten to suit the application.
- Since each valve and its components are different, packing gland torque numbers are unimportant. The best way to assure a proper seal is careful testing and adjustment.

PACKING REPLACEMENT AND/OR INNERVALVE REPLACEMENT

Valves with ratings of 30,000 psi, 40,000 psi and 60,000 psi, having a threaded lower adapter, are of similar construction. The stem packing and innervalue loaded through the top of the body, with the seat loaded through the bottom of the body.


To replace the packing:

1. Remove the valve to a suitable workspace.
2. If the unit has an Air-To-Open actuator, raise the innervalue (43a) using air to offset the seat sufficiently to unthread the innervalue stem from the actuator stem (7). Lay the actuator to the side, with the air pressure still on the diaphragm.
3. Once separated, loosen and remove the yoke lock nut and lift off the actuator.
4. Unthread the packing gland (35) and remove the innervalue.
5. Remove the lower threaded adapter (42) and slide the seat (43b) from the body (36).
6. Using a brass or aluminum rod up through the lower body cavity, gently tap the lower adapter until the packing components loosen and fall out. Notice the order of each component as it falls out of the body cavity. At this point, the upper packing follower (39) should come out easily.
7. Using the push rod, push the remaining packing cavity components from the packing cavity.
8. Clean and inspect the cavity using solvent and a soft brush. DO NOT use sandpaper or abrasives. Any visible marks can cause leakage.
9. If damage to the bore is noticed, the body will need to be replaced.
10. Use silicone grease or Krytox lubrication on the lower packing adapter (38) and slide gently to the bottom.
11. Using a plastic tweezers, lower the first ring into the cavity bore sideways until the ring is inside the 0.375 inch bore, past the threads and entrance.
12. Using a 1/8 inch diameter plastic rod, tip the ring over so that the concave side is pointing to the bottom of the cavity.
13. Using a 5/16 inch diameter plastic rod, push the ring to the bottom of the cavity.
14. Repeat the installation of all packing rings until they are all installed.
15. Insert the upper packing follower (39) into the cavity, on top of the last ring.

NOTE: At this point, a new innervalue set may be installed.

16. Insert the innervalue into and through the packing.
17. Lubricate the packing gland threads and thread it into the body until it is finger tight (15 pounds per foot / ~20 Nm).
18. Retract the innervalue to the upright position, until it bottoms inside the packing gland.
19. Install the seat into the bottom of the body, rub the threads of the adaptor with copper grease (or similar grease) to prevent galling, then thread the lower adapter until it is hand tight.
20. Stroke the innervalue (do not rotate) to check for alignment of the innervalue in the seat. If dragging occurs, do not proceed until the innervalue can be replaced or inspected.
21. If the innervalue strokes smoothly, tighten the lower adapter to 55 pounds per foot (~75 Nm). As the body wears from seat replacement, the lower adapter may have to be tightened to a higher torque. Too high a torque can damage the valve seat.
22. With the actuator still at stroke, reinstall the actuator, tighten the yoke lock nut and reconnect the innervalue to the actuator stem.
23. Thread the stem adjuster all the way into the adjusting nut to keep the innervalue off the seat when air pressure is removed.
24. Adjust the actuator (ATO actuators only) pressure to 3 psi.
25. Carefully turn the stem adjusting nut counterclockwise until the innervalue just touches the seat.
26. Adjust the pressure to the actuator until the valve is at ~50% opening.
27. Tighten any jam nuts.
28. Test and adjust packing according to previous instructions.
29. Consult the factory for instruction regarding disassembly of the actuator.

HP-60 ULTRA HIGH PRESSURE VALVE ASSEMBLY (60,000 PSI)



HP-60 Parts and Materials List

| Item | Part No. | Qty | Description | Material |
|----------|-------------|-----|--------------------|----------------|
| 1 | 527588-0001 | 1 | Yoke | Steel |
| 2 | 526041-0001 | 1 | Spring case | Steel |
| 3 | 526042-0001 | 1 | Pressure case | Steel |
| 4 | 510031-0149 | 6 | Spring | 17-7 SST |
| 5 | 512698-0002 | 1 | Diaphragm | Buna-N |
| 6 | 512883-0001 | 1 | Retainer diaphragm | Steel |
| 7 | 527448-0001 | 1 | Stem | 316/316L SST |
| 8 | 512882-0001 | 1 | Piston | Aluminum |
| 9 | 400013-0085 | 1 | Screw 5/16-24 | Steel |
| 10 | 527628-0001 | 1 | Nut, travel stop | 300 series SST |
| 11 | 527589-0001 | 1 | Stem connector | 17-4 PH SST |
| 12 | 512879-0003 | 1 | Travel indicator | Nylon |
| 13 | 520391 | 1 | Connector 10-32 | 316/316L SST |
| 14 | 400013-0002 | 10 | Screw 5/16-18 | 300 series SST |
| 15 | 430004-0021 | 12 | Lock washer | 300 series SST |
| 16 | 410001-0060 | 10 | Nut 5/16-18 | 300 series SST |
| 17 | 430002-0107 | 24 | Washer 5/16 | 300 series SST |
| 18 | 512880-0001 | 1 | Upper bushing | Nylatron |
| 19 | 460019-0001 | 1 | Lower bushing | Polymer |
| 20 | 490018-0003 | 1 | O-ring | Elf nitrile |
| 21 | 512712-0001 | 1 | Gasket | Carbon/nitrile |
| 22 | 527233-0004 | 1 | Travel scale | Aluminum |
| 23 | 400006-0056 | 1 | Set screw | 300 series SST |
| 24 | 512923-0001 | 1 | Nameplate | 300 series SST |
| 25 | 526037-0001 | 1 | Vent plug | Plastic |
| 26 | 526119-0002 | 6 | Screw 1/4-20 | Steel/fluro |
| 27 | 410001-0058 | 1 | Nut 5/16-24 | 300 series SST |
| 28 | 400001-0013 | 2 | Screw 6-32 | 300 series SST |
| 29 | 410011 | 1 | Nut 10-32 | 300 series SST |
| 30 | 527432-0001 | 1 | Washer thrust | Steel |
| 31 | 430004-0014 | 6 | Lock washer 1/4 | 300 series SST |
| 32 | 512717-0001 | 1 | Caution decal | Mylar |
| 33 | 512914-0002 | 1 | Decal | Vinyl/mylar |
| 34 or 34 | 541859 | 1 | Packing set | GF PTFE & PFA |
| 34 | 544489-0001 | 1 | Packing set | Torlon & PFA |
| 35 | 522622-0003 | 1 | Packing gland | 300 series SST |
| 36 | 529048-0001 | 1 | Body & bonnet | 17-4 PH SST |
| 37 | 526328-0001 | 1 | Yoke lock nut | 316/316L SST |
| 38 | 523185-0003 | 1 | Adapter | 17-4 PH SST |
| 39 | 522774-0003 | 1 | Follower | 17-4 PH SST |
| 40 | 522569 | 1 | Adapter lock | Brass |
| 41 | 400006-0045 | 1 | Set screw | 300 series SST |
| 42 | 522694-0003 | 1 | Lower adapter | 17-4 PH SST |
| 43a | — | 1 | Innervalue | — |
| 43b | — | 1 | Seat | — |
| 44 | 500458-0025 | — | Grease | — |
| 45 | 527624-0002 | 1 | Spring spacer | PVC |
| 46 | 528911-0001 | 1 | Spacer | 300 series SST |
| 47 | 400013-0088 | 2 | Screw | 300 series SST |
| 48 | 410001-0072 | 2 | Nut | 18-8 SST |
| 49 | 501658-0001 | 1 | Cap | Vinyl |


HP-60 Trim Chart

| Trim Size | Max. Cv | Orifice Dia. (in.) | Orifice Area (sq. in.) |
|-----------|---------|--------------------|------------------------|
| I* | 0.08 | 0.1000 | 0.0079 |
| J* | 0.05 | 0.1000 | 0.0079 |
| K | 0.03 | 0.0860 | 0.0058 |
| L | 0.02 | 0.0860 | 0.0058 |
| M | 0.01 | 0.0860 | 0.0058 |
| N | 0.006 | 0.0860 | 0.0058 |
| O | 0.003 | 0.0860 | 0.0058 |
| P-1 | 0.002 | 0.0625 | 0.0031 |
| P-2 | 0.0013 | 0.0625 | 0.0031 |
| P-3 | 0.001 | 0.0625 | 0.0031 |
| P-4 | 0.0006 | 0.0625 | 0.0031 |
| P-5 | 0.0004 | 0.0625 | 0.0031 |
| P-6 | 0.00027 | 0.0625 | 0.0031 |

* Special order

HP-40 ULTRA HIGH PRESSURE VALVE ASSEMBLY (40,000 PSI)

HP-40 Parts and Materials List




HP-40 Trim Chart

| Trim Size | Max. Cv | Orifice Dia. (in.) | Orifice Area (sq. in.) |
|-----------|---------|--------------------|------------------------|
| I* | 0.08 | 0.1000 | 0.0079 |
| J* | 0.05 | 0.1000 | 0.0079 |
| K | 0.03 | 0.0860 | 0.0058 |
| L | 0.02 | 0.0860 | 0.0058 |
| M | 0.01 | 0.0860 | 0.0058 |
| N | 0.006 | 0.0860 | 0.0058 |
| O | 0.003 | 0.0860 | 0.0058 |
| P-1 | 0.002 | 0.0625 | 0.0031 |
| P-2 | 0.0013 | 0.0625 | 0.0031 |
| P-3 | 0.001 | 0.0625 | 0.0031 |
| P-4 | 0.0006 | 0.0625 | 0.0031 |
| P-5 | 0.0004 | 0.0625 | 0.0031 |
| P-6 | 0.00027 | 0.0625 | 0.0031 |

* Special order

| Item | Part No. | Qty | Description | Material |
|----------|-------------|-----|--------------------|----------------|
| 1 | 527588-0001 | 1 | Yoke | Steel |
| 2 | 526041-0001 | 1 | Spring case | Steel |
| 3 | 526042-0001 | 1 | Pressure case | Steel |
| 4 | 510031-0149 | 6 | Spring | 17-7 SST |
| 5 | 512698-0002 | 1 | Diaphragm | Buna-N |
| 6 | 512883-0001 | 1 | Retainer diaphragm | Steel |
| 7 | 527448-0001 | 1 | Stem | 316/316L SST |
| 8 | 512882-0001 | 1 | Piston | Aluminum |
| 9 | 400013-0085 | 1 | Screw 5/16-24 | Steel |
| 10 | 527628-0001 | 1 | Nut, travel stop | 300 series SST |
| 11 | 527589-0001 | 1 | Stem connector | 17-4 PH SST |
| 12 | 512879-0003 | 1 | Travel indicator | Nylon |
| 13 | 520391 | 1 | Connector 10-32 | 316/316L SST |
| 14 | 400013-0002 | 10 | Screw 5/16-18 | 300 series SST |
| 15 | 430004-0021 | 12 | Lock washer | 300 series SST |
| 16 | 410001-0060 | 10 | Nut 5/16-18 | 300 series SST |
| 17 | 430002-0107 | 24 | Washer 5/16 | 300 series SST |
| 18 | 512880-0001 | 1 | Upper bushing | Nylatron |
| 19 | 460019-0001 | 1 | Lower bushing | Polymer |
| 20 | 490018-0003 | 1 | O-ring | Elf nitrile |
| 21 | 512712-0001 | 1 | Gasket | Carbon/nitrile |
| 22 | 527233-0004 | 1 | Travel scale | Aluminum |
| 23 | 400006-0056 | 1 | Set screw | 300 series SST |
| 24 | 512923-0001 | 1 | Nameplate | 300 series SST |
| 25 | 526037-0001 | 1 | Vent plug | Plastic |
| 26 | 526119-0002 | 6 | Screw 1/4-20 | Steel/fluro |
| 27 | 410001-0058 | 1 | Nut 5/16-24 | 300 series SST |
| 28 | 400001-0013 | 2 | Screw 6-32 | 300 series SST |
| 29 | 410011 | 1 | Nut 10-32 | 300 series SST |
| 30 | 527432-0001 | 1 | Washer thrust | Steel |
| 31 | 430004-0014 | 6 | Lock washer 1/4 | 300 series SST |
| 32 | 512717-0001 | 1 | Caution decal | Mylar |
| 33 | 512914-0002 | 1 | Decal | Vinyl/mylar |
| 34 or 34 | 541859 | 1 | Packing set | GF PTFE & PFA |
| 34 | 544489-0001 | 1 | Packing set | Torlon & PFA |
| 35 | 522622-0003 | 1 | Packing gland | 300 series SST |
| 36 | 529048-0001 | 1 | Body & bonnet | 17-4 PH SST |
| 37 | 526328-0001 | 1 | Yoke lock nut | 316/316L SST |
| 38 | 523185-0003 | 1 | Adapter | 17-4 PH SST |
| 39 | 522774-0003 | 1 | Follower | 17-4 PH SST |
| 40 | 522569 | 1 | Adapter lock | Brass |
| 41 | 400006-0045 | 1 | Set screw | 300 series SST |
| 42 | 522694-0003 | 1 | Lower adapter | 17-4 PH SST |
| 43a | — | 1 | Innervalue | — |
| 43b | — | 1 | Seat | — |
| 44 | 500458-0025 | — | Grease | — |
| 45 | 527624-0002 | 1 | Spring spacer | PVC |
| 46 | 528911-0001 | 1 | Spacer | 300 series SST |
| 47 | 400013-0088 | 2 | Screw | 300 series SST |
| 48 | 410001-0072 | 2 | Nut | 18-8 SST |
| 49 | 501658-0001 | 1 | Cap | Vinyl |

HP-30 ULTRA HIGH PRESSURE VALVE ASSEMBLY (30,000 PSI)



HP-30 Parts and Materials List

| Item | Description | Material |
|------|----------------|--------------|
| 1 | CVH Packing | TFE |
| 2 | Packing Gland | 303 SST |
| 3 | Body/Bonnet | 316/316L SST |
| 4 | Locknut | 300 SER SST |
| 5 | Connector | 316/316L SST |
| 6 | Adaptor | 416 SST |
| 7 | Follower | 416 SST |
| 8 | Adaptor, Lower | 316/316L SST |
| 9 | Adaptor Lock | Brass |
| 10 | Set Screw | SST |
| 11a | Stem | — |
| 11b | Innervalue | — |
| 11c | Seat | — |

HP-30 Trim Chart

| Trim Size | Max. Cv | Orifice Dia. in. (mm) | Orifice Area (sq. in.) |
|-----------|---------|--------------------------|---------------------------|
| I* | 0.08 | 0.1000 (2.54) | 0.0079 |
| J* | 0.05 | 0.1000 (2.54) | 0.0079 |
| K | 0.03 | 0.0860 (2.18) | 0.0058 |
| L | 0.02 | 0.0860 (2.18) | 0.0058 |
| M | 0.01 | 0.0860 (2.18) | 0.0058 |
| N | 0.006 | 0.0860 (2.18) | 0.0058 |
| O | 0.003 | 0.0860 (2.18) | 0.0058 |
| P-1 | 0.002 | 0.0625 (1.59) | 0.0031 |
| P-2 | 0.0013 | 0.0625 (1.59) | 0.0031 |
| P-3 | 0.001 | 0.0625 (1.59) | 0.0031 |
| P-4 | 0.0006 | 0.0625 (1.59) | 0.0031 |
| P-5 | 0.0004 | 0.0625 (1.59) | 0.0031 |
| P-6 | 0.00027 | 0.0625 (1.59) | 0.0031 |

* Special order

Control. Manage. Optimize.

Research Control is a registered trademark of Badger Meter, Inc. Other trademarks appearing in this document are the property of their respective entities. Due to continuous research, product improvements and enhancements, Badger Meter reserves the right to change product or system specifications without notice, except to the extent an outstanding contractual obligation exists. © 2021 Badger Meter, Inc. All rights reserved.

www.badgermeter.com