

Water Quality Monitors

Q45H/84 External DC Power H₂O₂ Monitor



CONTENTS

- Introduction5
 - General5
 - Standard System5
 - Features7
 - Q45/84 System Specifications.8
 - Q45 Performance Specifications8
- Analyzer Mounting9
 - General9
 - Wall or Pipe Mount10
- Sensor/Flowcell Mounting12
 - General12
 - Constant-Head Flowcell12
 - Sealed Flowcell13
- Electrical Installation14
 - General14
 - External Power15
 - Voltage Outputs17
 - Sensor Wiring17
 - Direct Sensor Connection17
 - Junction Box Connection18
- Sensor Assembly19
 - H₂O₂ Sensor Preparation19
- Configuration20
 - User Interface20
 - Keys20
 - Display.21
 - Software22
 - Software Navigation22
 - Measure Menu [MEASURE]24
 - Calibration Menu [CAL]25
 - Configuration Menu [CONFIG].25
 - Control Menu [CONTROL].26
 - Diagnostics Menu [DIAG]27
- Calibration29

Hydrogen Peroxide Calibration	29
H ₂ O ₂ Zero Cal.	29
H ₂ O ₂ Span Cal	30
Temperature Calibration	31
System Maintenance	32
General	32
Analyzer Maintenance	32
Peroxide Sensor Maintenance	32
Sensor Acid Cleaning	33
Flowcell Maintenance.	33
Troubleshooting	34
General	34
External Sources of Problems	34
Analyzer Tests	34
Display Messages	35
Sensor Tests	36
Spare Parts	37

INTRODUCTION

General

The Model Q45H/84 is an online monitoring system designed for the continuous measurement of hydrogen peroxide (H_2O_2) concentration in water. The full scale operating range of the system may be selected by the user for 0...2.000 ppm, 0...20.00 ppm or 0...200.0 ppm, and the sensing system operates on water streams with temperatures ranging from 0...50° C. The Q45H/84 monitor is engineered for applications in which H_2O_2 is applied to water for sterilization purposes.

The basic sensing element used in the monitor is a polarographic membraned sensor that measures hydrogen peroxide directly. Water simply flows past the sensor and directly to drain, with the flow rate and pressure across the sensor controlled by a constant head flowcell assembly. The sensor measurement does not alter the sample or add any chemicals to the sample stream, so the water flow can return to the system if desired.

Q45H/84 monitors are available in three electronic versions: a loop-powered 2-wire transmitter, a dual "AA" battery operated portable unit with two voltage outputs and a 5...17V DC externally powered unit with two voltage outputs. This manual refers to the 5...17V DC external transmitter version.

Standard System

The standard model Q45H/84 system includes three main components: the Q45/84 analyzer, a constant head flowcell and a H_2O_2 sensor. A sealed flowcell is also available for applications where sample flow rate and pressure can be carefully controlled. [Figure 1](#) shows a typical installation.

For connection of the sensor to the electronics, a 25 ft cable is supplied. An additional 100 ft of interconnect cable may be added using part number 07-0100 junction box. All required spare parts are also provided with the basic system, including spare membranes, electrolyte, O-rings and any special hardware.




Figure 1: Typical monitoring system

Figure 2 shows an installation using a sealed flowcell (00-1522) for the Peroxide sensor. This type of installation requires careful flow control. We recommend using our flow control assembly (03-0371) when using sealed flowcells. This assembly consists of an in-line filter and a fixed-flow regulator that maintains a constant 400 cc/min. flow rate through the system. This flow is maintained so long as inlet pressures are between 5...125 PSIG. The in-line filter is used mainly to protect the flow control element against larger particles that might cause plugging of the device.




Figure 2: System with sealed flowcell assembly

Features

- Standard Q45/84 electronic transmitters are designed to be fully-isolated, external powered for V DC applications.
- High accuracy, high sensitivity system, measures from 0.1 ppb...200.0 ppm through 4 internal automatic ranges. User ranges of 200.0 ppb, 2.000 ppm, 20.00 ppm or 200.0 ppm.
- *Output Hold, Output Simulate, Output Alarm* and *Output Delay* functions. All forced changes in output condition include bumpless transfer to provide gradual return to on-line signal levels and to avoid system control shocks on both analog outputs.
- Large, high contrast, custom LCD display with LED back light provides excellent readability in any light conditions. The secondary line of display utilizes 5×7 dot matrix characters for clear message display. Two of four measured parameters may be on the display simultaneously.
- Diagnostic messages provide a clear description of any problem with no confusing error codes to look up. Messages are also included for diagnosing calibration problems.
- Quick and easy one-point calibration method and sensor zero-cal. To provide high accuracy, all calibration methods include stability monitors that check temperature and main parameter stability before accepting data.
- High accuracy, three-wire Pt100 temperature input. Temperature element can be user calibrated.
- Security lock feature to prevent unauthorized tampering with transmitter settings. All settings can be viewed while locked, but they cannot be changed.



Equipment bearing this marking may not be discarded by traditional methods in the European community after August 12, 2005, per EU Directive 2002/96/EC. End users must return old equipment to the manufacturer for proper disposal.

Q45/84 System Specifications

Displayed Parameters	Main input, 0.001 ppm...200.0 ppm Sensor temperature, -10.0...55.0° C (23...131° F) Sensor Current, 0.0...999.9 nA, 0.000...99.99 µA Voltage Outputs, 0...2.5V Sensor slope/offset Model number and software version
Main Parameter Ranges	Manual selection of one of the following ranges: 0.0...2.000 ppm 0.00...20.00 ppm 0.00...200.0 ppm
Display	0.75 in. (19.05 mm) high 4-digit main display with sign 12-digit secondary display, 0.30 in. (7.62 mm) 5 × 7 dot matrix.
Keypad	4-key membrane type with tactile feedback, polycarbonate with UV coating
Weight	1 lb (0.45 kg)
Ambient Temperature	Analyzer Service, -20...60° C (-4...140° F) Sensor Service, -5...55° C (23...131° F) Storage, -5...70° C (-22...158° F)
Ambient Humidity	0...95%, indoor/outdoor use, non-condensing to rated ambient temperature range
Altitude	Maximum 2000 m (6562 ft)
Electrical Certification	Ordinary Location, cCSAus (CSA and UL standards - both approved by CSA), pollution degree 2, installation category 2
EMI/RFI Influence	Designed to EN 61326-1
Output Isolation	600V galvanic isolation
Temperature Input	Pt100 RTD with automatic compensation
Sensor	3-electrode polarographic membraned sensor for direct measurement of H ₂ O ₂
Sensor Materials	PVC
Sensor Cable	25 ft (7.5 m) cable with 6-pin plug
Max. Sensor-to-Analyzer Distance	100 ft (30.5 m), with junction box
Flowcell	Constant head overflow, clear cast acrylic, 7...30 GPH, 15 GPH recommended, inlet is 1/4 in. hose barb at 1/8 in. MNPT, outlet is 1/2 in. hose barb at 3/8 in. MNPT
Power	5...17V DC
Enclosure	NEMA 4X, IP66, polycarbonate, stainless steel hardware, weatherproof and corrosion resistant, HWD: 4.40 in. (111.76 mm) × 4.40 in. (111.76 mm) × 3.50 in. (88.90 mm)
Mounting Options	Wall or pipe mount bracket standard. Bracket suitable for either 1.50 in. or 2 in. I.D. U-bolts for pipe mounting.
Conduit Openings	Three PG-9 openings with gland seals
DC Cable Type	Belden twisted-pair, shielded, 22 gauge or larger

Q45 Performance Specifications

Accuracy	0.5% of selected range or 0.01 PPM
Repeatability	0.3% of selected range or 0.01 PPM
Sensitivity	0.05% of selected range
Non-linearity	0.1% of selected range
Warm-up Time	3 seconds to rated performance (electronics only)
Supply Voltage Effects	±0.05% span
Instrument Response Time	60 seconds to 90% of step input at lowest damping

ANALYZER MOUNTING

General

All Q45 Series instruments offer maximum mounting flexibility. A bracket is included with each unit that allows mounting to walls or pipes. In all cases, choose a location that is readily accessible for calibrations. Also consider that it may be necessary to utilize a location where solutions can be used during the calibration process. To take full advantage of the high contrast display, mount the instrument in a location where the display can be viewed from various angles and long distances.

Locate the instrument in close proximity to the point of installation; this allows easy access during calibration. The sensor-to-instrument distance should not exceed 100 ft. To maximize signal-to-noise ratio however, work with the shortest sensor cable possible. The standard cable length of the H₂O₂ sensor is 25 ft.

See [Figure 5 on page 11](#) and [Figure 6 on page 11](#) for mounting diagrams for each option.




Figure 3: Enclosure dimensions

Wall or Pipe Mount

A PVC mounting bracket with attachment screws is supplied with each transmitter (see [Figure 4](#) for dimensions). The multipurpose bracket is attached to the rear of the enclosure using the four flat head screws. The instrument is then attached to the wall using the four outer mounting holes in the bracket. These holes are slotted to accommodate two sizes of U-bolts that may be used to pipe mount the unit. Slots accommodate U-bolts designed for 1-1/2 in. or 2 in. pipe. The actual center-to-center dimensions for the U-bolts are shown in the drawing.

NOTE: These slots are for U-bolts with 1/4-20 threads. The 1-1/2 in. pipe U-bolt (2 in. I.D. clearance) is available from Badger Meter in type 304 stainless steel under part number 47-0005.




Figure 4: Wall or pipe mount bracket





Figure 5: Wall mount diagram



NOTE: Mounting plate hole spacing can support up to 2.00 in. (50.80 mm) Ø pipe max.

Figure 6: Pipe mounting diagram

SENSOR/FLOWCELL MOUNTING

General

Select a location within the maximum sensor cable length for mounting of the sensor flowcell.

Constant-Head Flowcell

H₂O₂ sensors are best used in a constant-head overflow chamber because variations in sample flow rate and pressure can cause unstable readings. When monitoring low concentrations (below 0.5 PPM), this method should always be used.

Mechanical installation of the flowcell requires that it be mounted to a wall or other convenient flat surface. Alternatively, the mounting holes on the plate accommodate a 2 in. U-bolt for mounting the plate to a 2 in. pipe. [Figure 7](#) shows the dimensions and mounting hole locations for the flowcell. Be sure to allow enough clearance on the left side of the flowcell for insertion and removal of the sensor. About 12 in. clearance is recommended.




Figure 7: Constant head flowcell details

Once mounted, inlet and drain connections must be made. The flowcell contains a 1/8 in. MNPT inlet connection and a 3/8 in. MNPT drain connection. Hose barbs for the inlet and drain connections are supplied with the flowcell for use with flexible tubing. The inlet hose barb is used with 1/4 in. I.D. tubing and the drain hose barb is used with 1/2 in. I.D. tubing.

Sealed Flowcell

Applications where the sample inlet flow is well controlled can use a simpler sealed flowcell. Using this flowcell requires that flow be controlled externally to about 400 cc/min. Variable flow rate or variable pressure cause unstable readings in this flowcell. Badger Meter offers a special flow control element that can be used ahead of this flowcell on the incoming sample line. The flow control is part number (55-0048). It controls the inlet flow rate at 400 cc/min. with inlet pressure variations from 5...150 PSIG. A 50 micron Y-strainer ahead of the flow control element is recommended. The sealed flowcell provides a drain vent with check valve to avoid pulling a vacuum on the flow chamber.




Figure 8: Sealed flowcell details

ELECTRICAL INSTALLATION

General

The Q45, 5...17V DC externally powered transmitter is designed for low power operation for solar power applications. Verify the type of unit before connecting any power.

WARNING

DO NOT CONNECT AC LINE POWER TO THE PCB MODULE. SEVERE DAMAGE RESULTS.

IMPORTANT NOTES:

1. Use wiring practices that conform to all national, state and local electrical codes. For proper safety as well as stable measuring performance, it is important that the earth ground connection be made to a solid ground point from Terminal 10 shown in [Figure 9 on page 15](#).
2. Do NOT run sensor cables or instrument output wiring in the same conduit that contains AC power wiring. AC power wiring should be run in a dedicated conduit to prevent electrical noise from coupling with the instrumentation signals.

External Power

Q45H units ordered with the external connection option are designed for applications where power is to be supplied from an external source, and the two voltage outputs are to be wired to an external device. [Figure 10 on page 16](#) identifies the terminal connections for external powers.




Figure 9: Sensor connection

NOTE: Earth ground into Terminal 10 is HIGHLY recommended. This connection can greatly improve stability in electrically noisy environments.

The external power board contains 3 switch assemblies as shown in the drawings.

The first (S1) is an On/Off slide switch. This switch must be in the ON position for operation. Turn it to OFF if you do not intend to operate the monitor in the next week or two.

The second switch assembly (S2) contains two switches, the one on the left marked LOCK and the one on the right marked MODE. The function of these two slide switches are as follow:

- **LOCK**

This switch is used to define how the monitor turn on and off. This switch is normally in the OFF position. With the lock switch off, the monitor turns on manually using the **MENU** key on the front of the monitor. With the lock switch in the ON position, the monitor is always be on when there is enough power to run the monitor. The ON position is normally used when operating from an external power supply intended for continuous operation.

- **MODE**

This switch reserved for Battery Powered Operation. **There is no function when used with external power transmitter.**

The switch assembly is a single slide switch (S3) that defines whether the 0...2.5V DC signals from the monitor are isolated or non-isolated. Output isolation is not required when outputs are connected to a data logging device. However, if the outputs are connected to external devices, putting this switch in the ISO position protects against possible ground loops. The isolation circuit slightly increases the power requirement of the monitor.




Figure 10: External power board

Voltage Outputs

There are two sets of analog voltage outputs on the board that may be used to send isolated data back to remotely located recorders, PLCs and more. *Output #1* is used only for H₂O₂, and *Output #2* can be used for either PPM or temperature.

Sensor Wiring

The sensor cable can be quickly connected to the Q45 terminal strip by matching the wire colors on the cable to the color designations on the label in the monitor. A junction box is also available to provide a break point for long sensor cable runs. Route signal cable away from AC power lines, adjustable frequency drives, motors or other noisy electrical signal lines. Do not run sensor or signal cables in conduit that contains AC power lines or motor leads.

Direct Sensor Connection

Sensor connections are made in accordance with [Figure 9 on page 15](#). The sensor cable can be routed into the enclosure through one of the cord grips supplied with the unit. Routing sensor wiring through conduit is only recommended if a junction box is used. Some loose cable is needed near the installation point so that the sensor can be inserted and removed easily from the flowcell.

Cord grips used for sealing the cable should be snugly tightened after electrical connections have been made to prevent moisture incursion. When stripping cables, leave adequate length for connections in the transmitter enclosure as shown in [Figure 11](#). The standard 25 ft sensor cable normally supplied with the system is already stripped and ready for wiring. This cable can be cut to a shorter length if desired to remove extra cable in a given installation. Do not cut the cable so short as to make installation and removal of the sensor difficult.




Figure 11: Sensor cable preparation

Junction Box Connection

For installations where the sensor is located more than 25 ft from the monitor (max. 100 ft), a junction box must be used. The junction box is shown in [Figure 12](#) and is supplied with a 1/2 in. conduit hub on one end and a sensor cable gland on the other end.




Figure 12: Junction box interconnect wiring

SENSOR ASSEMBLY

H₂O₂ Sensor Preparation

The hydrogen peroxide sensor supplied with the Q45/84 is shipped dry. It does not operate until it is prepared by adding electrolyte and a membrane. Preparation of the sensor for operation must be done carefully. The procedure should be done by a qualified technician, and it should only be done when the system is ready for operation. Until then, it is best to leave the sensor in the condition in which it is received.




Figure 13: H₂O₂ sensor assembly

Follow the procedure below to prepare the sensor for operation:

⚠ CAUTION

USE EXTREME CARE WHEN FILLING THE H₂O₂ SENSOR WITH ELECTROLYTE. THE ELECTROLYTE IS VERY ACIDIC AND CAN CAUSE EYE AND SKIN DAMAGE. GETTING THE ELECTROLYTE ON CLOTHING PROBABLY RESULTS IN HOLES APPEARING AFTER WASHING. WEAR LATEX GLOVES AND EYE PROTECTION WHEN FILLING THE SENSOR.

1. Unscrew the electrolyte chamber from the assembled sensor and remove the vent screw from the side of the sensor body.
2. Remove the front nut from the bottom of the chamber and discard the protective membrane. O-rings are contained in grooves on both the bottom and top of the chamber. Be sure that these O-rings remain in place.
3. From the package of membranes supplied with the sensor, place a new membrane into the front nut. The membrane is white in color and is separated from other membranes by a light blue paper spacer.
4. Screw the front nut onto the chamber until you feel the O-ring compress. Hand tight compression is all that is needed. Do not use tools to tighten. The membrane should be flat across the bottom of the chamber without wrinkles.
5. Fill the chamber with electrolyte until the level reaches the bottom of the internal threads.
6. Slowly screw the chamber onto the sensor body. A small amount of electrolyte runs out of the hole from which the vent screw was removed. Place a paper towel around the sensor to absorb the electrolyte overflow. Use **EXTREME** caution when handling electrolyte. Hand-tighten the chamber until the O-ring at the top of the chamber is compressed. Do not use tools to tighten.
7. Shake excess electrolyte from the fill hole on the side of the sensor and replace the vent screw.

The sensor is now ready for operation. The membrane should be stretched tightly across the tip of the sensor.

⚠ CAUTION

WHEN HANDLING THE ASSEMBLED SENSOR, DO NOT SET THE SENSOR ON ITS TIP OR DAMAGE TO THE MEMBRANE RESULTS. SEVERE IMPACTS ON THE TIP OF THE SENSOR FROM DROPPING OR OTHER MISUSE MAY CAUSE PERMANENT DAMAGE TO THE SENSOR.

CONFIGURATION

User Interface

The user interface for the Q45 Series instrument consists of a custom display and a membrane keypad. All functions are accessed from this user interface (no internal jumpers or pots, for example).




Figure 14: User interface

Keys

All user configuration occurs through the use of four membrane keys. These keys are used as follows:

MENU/ESC	To scroll through the menu section headers or to escape from anywhere in software. The escape sequence allows the user to back out of any changes in a logical manner. Using the ESC key aborts all changes to the current screen and backs the user out one level in the software tree. The manual refers to this key as either MENU or ESC, depending upon its particular function.
UP (arrow)	To scroll through individual list or display items and to change number values.
LEFT (arrow)	To move the cursor from right to left during changes to a number value.
ENTER	To select a menu section or list item for change and to store any change.

Display

The large custom display provides clear information for general measurement use and user configuration. There are three main areas of the display: the main parameter display, the secondary message line and the icon area.

Main Parameter During normal operation, the main parameter display indicates the present process input with sign and units. This main display may be configured to display any of the main measurements that the system provides. During configuration, this area displays other useful setup information to the user.



Lower Line During normal operation, the lower line of the display indicates user-selected secondary measurements that the system is making. This also includes calibration data from the last calibration sequence and the transmitter model number and software version. During configuration, the lower line displays menu items and setup prompts to the user. Finally, the lower line displays error messages when necessary. For a description of all display messages, see ["Display Messages" on page 35](#).



Icon Area The icon area contains display icons that assist the user in setup and indicate important states of system functions. The *CAL*, *CONFIG* and *DIAG* icons are used to tell the user what branch of the software tree the user is in while scrolling through the menu items. This improves software map navigation dramatically. Upon entry into a menu, the title displays (such as *CAL*) and then the title disappears to make way for the actual menu item. However, the icon stays on.



HOLD The *HOLD* icon indicates that the current output of the transmitter has been put into output hold. In this case, the output is locked to the last input value measured when the *HOLD* function was entered. *HOLD* values are retained even if the unit power is cycled.

FAIL The *FAIL* icon indicates that the system diagnostic function has detected a problem that requires immediate attention. This icon is automatically cleared once the problem has been resolved.

Software

The software of the Q45H is organized in an easy to follow menu-based system. All user settings are organized under five menu sections: *Measure*, *Calibration [CAL]*, *Configuration [CONFIG]*, *Control [CONTROL]* and *Diagnostics [DIAG]*.

NOTE: The default *Measure* menu is display-only and has no menu icon.

Software Navigation

Within the *CAL*, *CONFIG*, *CONTROL* and *DIAG* menu sections is a list of selectable items. Once a menu section (such as *CONFIG*) has been selected with the **MENU** key, the user can access the item list in this section by pressing either the **ENTER** key or the **UP** arrow key. The list items can then be scrolled through using the **UP** arrow key. Once the last item is reached, the list wraps around and the first list item is shown again. The items in the menu sections are organized such that more frequently used functions are first, while more permanent function settings are later in the list. See [Figure 15 on page 23](#) for a visual description of the software.

Each list item allows a change to a stored system variable. List items are designed in one of two forms: simple single variable or multiple variable sequence. In the single variable format, the user can quickly modify one parameter (for example, changing temperature display units from °F to °C). In the multiple variable sequence, variables are changed as the result of some process. For example, the calibration of H₂O₂ generally requires more than one piece of information to be entered. The majority of the menu items in the software consist of the single variable format type.

Any data that may be changed flashes. This flashing indicates *User Entry* mode and is initiated by pressing the **ENTER** key. The UP arrow key increases a flashing digit from 0...9. The LEFT arrow key moves the flashing digit from right to left. Once the change has been completed, pressing **ENTER** again stores the variable and stops the flashing. Pressing **ESC** aborts the change and also exits *User Entry* mode.

The starting (default) screen is always the *Measure* menu. The UP arrow key is used to select the desired display. From anywhere in this section the user can press the **MENU** key to select one of the four *Menu Sections*.

The UP arrow icon next to all list items on the display is a reminder to scroll through the list using the **UP** arrow key.

To select a list item for modification, first select the proper menu with the **MENU** key. Scroll to the list item with the **UP** arrow key and then press the **ENTER** key. This tells the system that the user wishes to perform a change on that item. For single item type screens, once the user presses the ENTER key, part or all of the variable begins to flash, indicating that the user may modify that variable using the arrow keys. However, if the instrument is locked, the transmitter displays the message, "Locked!" and does not enter *User Entry* mode. The instrument must be unlocked by entering the proper code value to allow authorized changes to user entered values. Once the variable has been reset, pressing the **ENTER** key again causes the change to be stored and the flashing to stop. The message, "Accepted!" displays if the change is within pre-defined variable limits. If the user decides not to modify the value after it has already been partially changed, pressing the **ESC** key aborts the modification and returns the entry to its original stored value.

In a menu item which is a multiple variable sequence type, once the ENTER key is pressed there may be several prompts and sequences that are run to complete the modification. The ESC key can always be used to abort the sequence without changing any stored variables.




Figure 15: Software map

Measure Menu [MEASURE]

The default menu for the system is the display-only menu *MEASURE*. This menu is a display-only measurement menu, and has no changeable list items. When left alone, the instrument automatically returns to this menu after approximately 30 minutes. While in the default menu, the UP arrow allows the user to scroll through the secondary variables on the lower line of the display. A brief description of the fields in the basic transmitter version is as follows:

TRANSMITTER MEASURE SCREENS:

25.7° C	Temperature display. Can display in °C or °F, depending on user selection. A small “m” on the left side of the screen indicates the transmitter has automatically jumped to a manual 25° C setting due to a failure with the temperature signal input.
32.0 nA	Raw sensor current. Useful for diagnosing problems.
#1 0.00V DC	Instrument output signal #1.
#2 1.25V DC	Instrument output signal #2.
Slope = 100%	Sensor output response vs. ideal calibration. This value updates after each calibration. As the sensor ages, the slope reading decays, indicating sensor aging. Useful for resolving sensor problems.
Offset = 0.0 nA	Sensor output current at a zero ppm input. This value updates after a zero-calibration has been performed. Useful for resolving sensor problems.
Q45S5 v4.02	Transmitter software version number.

NOTE: A display test (all segments ON) can be actuated by pressing and holding the **ENTER** key while viewing the model/version number on the lower line of the display.

The *MEASURE* screens are intended to be used as a very quick means of looking up critical values during operation or troubleshooting.

Calibration Menu [CAL]

The *Calibration* menu contains items for frequent calibration of user parameters. There are three items in this list: *Cal H₂O₂*, *Cal Temp* and *Set Range*.

- Cal H₂O₂** The *H₂O₂ Calibration* function allows the user to adjust the transmitter span reading to match a reference solution or to set the sensor zero point. See “*Calibration*” on page 29 for more details.
- Cal Temp** The *Temperature Calibration* function allows the user to adjust the offset of the temperature response by a small factor of $\pm 5^{\circ}$ C. The temperature input is factory calibrated to very high accuracy. However, long cable lengths and junction boxes may degrade the accuracy of the temperature measurement in some extreme situations. Therefore, this feature is provided as an adjustment. See “*Calibration*” on page 29 for more details.
- Set Range** This function allows the user to set the display range of the transmitter to a specific application. Once set, all output functions use this display range to establish configuration settings. Press **ENTER** to initiate *User Entry* mode, and the value flashes. Use the arrow keys to modify value; available ranges include 2.000 ppm, 20.00 ppm and 200.0 ppm. Press **ENTER** to store the new value. The display range does not affect the internal auto ranging scaler that, therefore, sensitivity is to specification in any user selected range.

Configuration Menu [CONFIG]

The *Configuration* menu contains all of the general user settings:

- Entry Lock** This function allows the user to lock out unauthorized tampering with instrument settings. All settings may be viewed while the instrument is locked, but they cannot be modified. The *Entry Lock* feature is a toggle-type setting; that is, entering the correct code locks the transmitter and entering the correct code again unlocks it. The code is preset at a fixed value. Press **ENTER** to initiate *User Entry* mode and the first digit flashes. Use arrow keys to modify value. See page 37 of this manual for the Q45 lock/unlock code. Press **ENTER** to toggle lock setting once code is correct. Incorrect codes do not change state of lock condition.
- Set Delay** The *Set Delay* function sets the amount of damping on the instrument. This function allows the user to apply a first order time delay function to the H₂O₂ measurements being made. Both the display and the output value are affected by the degree of damping. Functions such as calibration are not affected by this parameter. The calibration routines contain their own filtering and stability monitoring functions to minimize the calibration timing. Press **ENTER** to initiate *User Entry* mode, and the value flashes. Use the arrow keys to modify value; range is 0.1...9.9 minutes. Press **ENTER** to store the new value.
- Contrast** This function sets the contrast level for the display. The custom display is designed with a wide temperature range, Super-Twist Nematic (STN) fluid.
- The STN display provides the highest possible contrast and widest viewing angle under all conditions. Contrast control of this type of display is generally not necessary, so contrast control is provided as a means for possible adjustment due to aging at extreme ranges. In addition, the display has an automatic temperature compensation network. Press **ENTER** to initiate *User Entry* mode, and the value flashes. Use arrow keys to modify the value; range is 0...8 (0 being lightest). Press **ENTER** to update and store the new value.
- Main Units** This function allows the user to select either PPM or mg/l for the chlorine measurement.
- Zero Filter** This function forces the reading to zero when reading is below the entered value. For example, if the entered value were 0.0020 the display at 0.0019 would then indicate 0.0000. This feature is useful in blanking out zero noise.
- Main Display** This function allows the user to change the measurement in the primary display area. The user may select between chlorine, sensor temperature or output current. Using this function, the user may choose to put temperature in the main display area and chlorine on the secondary, lower line of the display. Press **ENTER** to initiate *User Entry* mode, and the entire value flashes. Use the **UP** arrow key to modify the desired display value. Press **ENTER** to store the new value.

- Out2 Mode** This function sets analog output #2 to either track PPM or temperature. Press **ENTER** to initiate *User Entry* mode, and the entire value flashes. Use the **UP** arrow key to modify the desired value; selections include 1-ppm for H₂O₂ tracking or 2-temperature. Press **ENTER** to store the new value.
- Temp Units** This function sets the display units for temperature measurement. Press **ENTER** to initiate *User Entry* mode, and the entire value flashes. Use the **UP** arrow key to modify the desired display value. The choices are °F and °C. Press **ENTER** to store the new value.

Control Menu [CONTROL]

The *Control* menu contains all of the output control user settings:

- Set 0V #1** These functions set the output range for each of the two instrument outputs. The value stored for the 0V point may be higher or lower than the value stored for the 2.5V point.
- Set 2.5V #1**
- Set 0V #2** The entry values are limited to values within the range selected in the *Set Range* parameter under the *CAL* menu and must be separated by at least 1% of this range. Use the **LEFT** arrow key to select the first digit to be modified. Then use the **UP** and **LEFT** arrow keys to select the desired numerical value. Press **ENTER** to store the new value.
- Set 2.5V #2**
- Output #1* is always be in units of ppm, as it is fixed to track hydrogen peroxide. *Output #2* is in either units of ppm or °C/°F, depending on whether hydrogen peroxide, or temperature is set for *Out#2* in the *CONFIG* menu.
- NOTE:** If the temperature units are changed between °C and °F (see “*Temp Units*”), the default settings for this output are stored (present data is not converted).

Diagnostics Menu [DIAG]

The *Diagnostics* menu contains all of the user settings that are specific to the system diagnostic functions, as well as functions that aid in troubleshooting application problems.

- Set Hold** The *Set Hold* function locks the current loop output values on the present process value. This function can be used prior to calibration, or when removing the sensor from the process, to hold the output in a known state. Once *HOLD* is released, the outputs return to their normal state of following the process input. The transfer out of *HOLD* is bumpless on the both analog outputs; the transfer occurs in a smooth manner rather than as an abrupt change. An icon on the display indicates the *HOLD* state, and the *HOLD* state is retained even if power is cycled. Press **ENTER** to initiate *User Entry* mode and entire value flashes. Use the **UP** arrow key to modify the desired value, selections are ON for engaging the *HOLD* function and OFF to disengage the function. Press **ENTER** to store the new value.
- The *Set Hold* function can also hold at an output value specified by the user. To customize the hold value, first turn the *HOLD* function on. Press the **ESC** key to go to the *DIAG* menu and scroll to *Sim Output* using the **UP** arrow key. Press **ENTER**. Follow the instructions under “*Sim Out*”.
- Fault List** The *Fault List* screen is a read-only screen that allows the user to display the cause of the highest priority failure. The screen indicates the number of faults present in the system and a message detailing the highest priority fault present.
- NOTE:** Some faults can result in multiple displayed failures due to the high number of internal tests occurring. As faults are corrected, they are immediately cleared.
- Faults are not stored; therefore, they are immediately removed if power is cycled. If the problem causing the faults still exists, however, faults display again after power is re-applied and a period of time elapses during which the diagnostic system re-detects them. The exception to this rule is the calibration failure. When a calibration fails, no corrupt data is stored. Therefore, the system continues to function normally on the data that was present before the calibration was attempted.
- After 30 minutes or if power to the transmitter is cycled, the failure for calibration clears until calibration is attempted again. If the problem still exists, the calibration failure reoccurs. Press **ENTER** to initiate view of the highest priority failure. The display automatically returns to normal after a few seconds.
- Sim Out** The *Sim Out* function allows the user to simulate the H_2O_2 level of the instrument in the user selected display range. The user enters a ppm value directly onto the screen, and the output responds as if it were actually receiving the signal from the sensor. This allows the user to check the function of attached monitoring equipment during setup or troubleshooting. Escaping this screen returns the unit to normal operation. Press **ENTER** to initiate the *User Entry* mode, and the rightmost digit of the value flashes. Use arrow keys to modify desired value.
- The starting display value is the last read value of the input. The output is under control of the *SIM* screen until the **ESC** key is pressed.
- NOTE:** If the *HOLD* function is engaged before the *Sim Output* function is engaged, the simulated output remains the same even when the **ESC** key is pressed. Disengage the *HOLD* function to return to normal output.
- Auto-Off** Enables the automatic shut-off feature for the instrument. If ON, the instrument automatically shuts off in 60 minutes after no keys are pressed to save power. With the external powered unit, this function should remain at OFF.
- Back-Light** The Backlight screen is used to set the operating conditions under which the backlight turns on. The default is AUTO, which configures the light to come on whenever any key is pressed. The light automatically shuts off if no key is pressed for 30 seconds. Other selections are OFF (always off), AL for Alarm, where the light comes on in alarm condition and flashes under a *FAIL* condition and ON (always on).

Set Default

The *Set Default* function allows the user to return the instrument back to factory default data for all user settings or for just the calibration default. It is intended to be used as a last resort troubleshooting procedure. All user settings or the calibration settings are returned to the original factory values. Hidden factory calibration data remains unchanged. Press **ENTER** to initiate *User Entry* mode and select either *CAL* or *ALL* with the **UP** arrow key. The default *CAL* routine resets the zero offset to 0.0 nA and reset the slope to 100%. The default *ALL* routine resets all program variables to factory default and should be used with care since it changes any user settings that were programmed in the field.

CALIBRATION

Hydrogen Peroxide Calibration

Once power is applied, the sensor must be given time to stabilize. This is best done by following the zeroing procedure below. Establishing a stable zero is critical to the proper operation of the monitor. A complete calibration includes zeroing and spanning the sensor. It is generally unnecessary to set the zero at every calibration, however, it should be done during the initial installation.

H₂O₂ Zero Cal

Hydrogen peroxide sensors have extremely low offset currents at zero. For this reason, it is normally sufficient to simply leave the zero at the factory default of 0.0 nA. As an alternative, an electronic zero can be set by disconnecting the sensor from the cable and performing steps 1...5 below.

The steps below assume that the sensor has been prepared in accordance with [“Sensor Assembly” on page 19](#).

NOTE: The 8 hour waiting time in step 2 below is not required if the monitor has been running for 24 hours prior to zeroing. If the unit has been running with the sensor connected, the sensor normally returns to a stable zero within 15 minutes.

1. Connect the sensor to the electronics by plugging the cable plug into the receptacle on the top of the sensor.
2. Place about an inch of water in a small beaker or other convenient container and immerse the tip of the sensor. The water used need not be distilled, but it must not contain hydrogen peroxide. If the sensor is being used for the first time, allow the sensor to sit undisturbed for at least 4 hours. If the sensor has been in use, 30...60 minutes is normally enough to establish a good zero.
3. Scroll to the *CAL* menu section using the **MENU** key and press **ENTER** or the **UP** arrow key. “Cal H₂O₂” then displays.
4. Press the **ENTER** key. The screen displays a flashing “1-Ref” for span calibration or a “2-Zer” for zero calibration. Using the **UP** arrow key, set for a 2-Zer zero calibration and press **ENTER**. The system now begins acquiring data for the sensor zero calibration value. As data is gathered, the units for sensor current in nanoamps (nA) and temperature may flash. Flashing units indicate that this parameter is unstable. The calibration data point acquisition stops only when the data remains stable for a pre-determined amount of time. This can be overridden by pressing **ENTER**. If the data remains unstable for 10 minutes, the calibration fails and the message, “Cal Unstable” displays.
5. If accepted, the screen displays the message, “PASS” with the new sensor zero reading (offset), and then it returns to the main measurement display. If the calibration fails, a message indicating the cause of the failure displays and the *FAIL* icon turns on. The range of acceptable value for sensor offset is -999...999 nA. Should a *FAIL* occur, carefully inspect the sensor for a tear in the membrane. It is probably necessary to rebuild the sensor as described in [“Sensor Assembly” on page 19](#). Should the offset value remain high and result in calibration failures, review the [“System Maintenance” on page 32](#), and then contact the service dept. at Badger Meter for further assistance.

The sensor zero offset value in nA from the last zero calibration displays on the lower line of the *Default* menus for information purposes.

H₂O₂ Span Cal

Span calibration of the system must be done against a laboratory measurement on the same sample that the sensor is measuring. A sample should be collected from the inlet line feeding the flowcell and quickly analyzed for H₂O₂. When calibrating, it is best to have a reasonably high concentration of H₂O₂ in the system. The higher the value, the smaller the calibration errors caused by errors in the laboratory analytical procedure. It is generally preferable to calibrate at values above 2 ppm to reduce calibration errors.

Start flowcell and calibrate system as follows:

1. Place the previously zeroed sensor into the sensor chamber of the flowcell assembly. The sensor is inserted into the side of the flowcell and is sealed in place with a double O-ring. The O-rings are lubricated at the factory to allow the sensor to slide smoothly into place. If insertion becomes difficult, use a small amount of silicon grease to lubricate the O-rings. If the low-volume flowcell is used, screw the sensor into the flowcell until the membrane cap bottoms out on the acrylic flowcell. Do not over-tighten.
2. Turn on the inlet water flow to the flowcell and adjust the inlet flow rate so that water is overflowing from the inlet chamber. The best performance is obtained when some water is always overflowing. This maintains constant flow and pressure on the sensor at all times.
3. Allow the system to operate undisturbed for 30...60 minutes. Assuming the water contains H₂O₂, the display reads positive sensor current values. If the system is stable, the value on the display increases to some PPM value and remains at that level. At that point, calibration can continue.
4. If the sensor is on-line, the user may want to set the output *HOLD* feature prior to calibration to lock out any output fluctuations.
5. Scroll to the *CAL* menu section using the **MENU** key and press **ENTER** or the **UP** arrow key. *Cal H₂O₂* displays.
6. Press the **ENTER** key. The screen displays a flashing "1-Ref" for span calibration or a "2-Zer" for zero calibration. Using the **UP** arrow key, set for a 1-Ref span calibration and press **ENTER**.
7. The system now begins acquiring data for the calibration value. As data is gathered, the units for ppm and temperature may flash. Flashing units indicate that this parameter is unstable. The calibration data point acquisition stops only when the data remains stable for a pre-determined amount of time. This can be overridden by pressing **ENTER**. If the data remains unstable for 10 minutes, the calibration fails and the message, "Cal Unstable" displays.
8. The screen displays the last measured ppm value and a message displays prompting the user for the lab value. The user must then modify the screen value with the arrow keys and press **ENTER**. The system then performs the proper checks.
9. If accepted, the screen displays the message, "PASS" with the new sensor slope reading, then it returns to the main measurement display. If the calibration fails, a message indicating the cause of the failure displays and the *FAIL* icon turns on. The range of acceptable values for sensor slope is 20...500%. It may be necessary to rebuild the sensor as described in ["Sensor Assembly" on page 19](#). Should the slope value remain out of range and result in calibration failures, review the ["System Maintenance" on page 32](#), and then contact the service department at Badger Meter for further assistance.

The sensor offset value in % from the last span calibration displays on the lower line of the *Default* menus for information purposes.

Temperature Calibration

The *Temperature Calibration* sequence is essentially a 1-point offset calibration that allows adjustments of approximately $\pm 5^{\circ}\text{C}$.

The sensor temperature may be calibrated on line, or the sensor can be removed from the process and placed into a known solution temperature reference. In any case, it is critical that the sensor be allowed to reach temperature equilibrium with the solution in order to provide the highest accuracy. When moving the sensor between widely different temperature conditions, it may be necessary to allow the sensor to stabilize as much as one hour before the calibration sequence is initiated. If the sensor is on-line, the user may want to set the output *HOLD* feature prior to calibration to lock out any output fluctuations.

1. Scroll to the *CAL* menu section using the **MENU** key and press **ENTER** or the **UP** arrow key.
2. Press the **UP** arrow key until *Cal Temp* displays.
3. Press the **ENTER** key. The message, "Place sensor in solution then press ENTER" displays. Move the sensor into the calibration reference (if it hasn't been moved already) and wait for temperature equilibrium to be achieved. Press **ENTER** to begin the calibration sequence.
4. The calibration data gathering process begins. The message, "Wait" flashes as data is accumulated and analyzed. The **°C** or **°F** symbol may flash periodically if the reading is too unstable.
5. The message, "Adjust value - press ENTER" displays, and the rightmost digit begins to flash, indicating that the value can be modified. Using the **UP** and **LEFT** arrow keys, modify the value to the known ref solution temperature. Adjustments up to $\pm 5^{\circ}\text{C}$ from the factory calibrated temperature are allowed. Press **ENTER**.

Once completed, the display indicates PASS or FAIL. If the unit fails, the temperature adjustment may be out of range, the sensor may not have achieved complete temperature equilibrium or there may be a problem with the temperature element. In the event of calibration failure, it is recommended to attempt the calibration again immediately.

SYSTEM MAINTENANCE

General

The Q45/84 Hydrogen Peroxide System generally provides unattended operation over long periods of time. With proper care, the system should continue to provide measurements indefinitely. For reliable operation, maintenance on the system must be done on a regular schedule. Keep in mind that preventive maintenance on a regular schedule is much less troublesome than emergency maintenance.

Analyzer Maintenance

No unusual maintenance of the analyzer is required if installed according to the guidelines of this user manual. If the enclosure door is frequently opened and closed, it would be wise to periodically inspect the enclosure sealing gasket for breaks or tears.

Peroxide Sensor Maintenance

Sensor maintenance is required for accurate measurements. The primary requirement is simply to keep the sensor membrane clean. The membrane is a micro-porous polymer that is resistant to anything that is encountered in water streams. However, deposits can form on the surface or in the pores of the membrane, and these deposits reduce the sensitivity. Certain constituents in water, mainly iron and manganese, form precipitates. These precipitates can sometimes form a coating on the membrane.

Because membranes are micro-porous, they can be relatively difficult to clean effectively. Immersing the tip of the sensor in 1N nitric acid solution sometimes removes deposits that cause low sensitivity, but this is not always the case. The recommended practice is to simply replace the membrane when it becomes fouled. To change a membrane, follow the [“Sensor Assembly” on page 19](#). Do not reuse the electrolyte from the sensor when changing a membrane. Always refill with fresh electrolyte. The electrolyte is stable and does not have a limited shelf life.

Refer again to the explanation of the sensor slope number after an accepted span calibration on the lower *MEASURE* screen. In normal operation, the slope of the sensor output decreases over time as the membrane becomes fouled. This reduction indicates that the sensor is losing sensitivity to H_2O_2 . It is good practice to replace the membrane if the slope number falls to 30...40%. The value does not go below 20%.

Even if no buildup is apparent on the membrane, it should be changed on a regular schedule. The recommended membrane change interval is every 3 months. For high purity water applications, this can probably be extended if desired, but a more frequent changing interval is a small price to pay for avoiding membrane failure at the wrong time.

While the sensor is disassembled for membrane changing, examine the condition of the O-rings on both ends of the electrolyte chamber. If the O-rings show any signs of damage, replace them with new ones from the spare parts kit. It is good practice to change these O-rings once a year, regardless of their condition.

Sensor Acid Cleaning

Over an extended operating period, H_2O_2 sensors can slowly accumulate deposits on the surfaces of the platinum cathode and counter electrodes. Typically, this type of buildup occurs over years of operation but can sometimes occur more quickly in high levels of manganese, iron or other metals that are dissolved in the water. The platinum electrodes can be “acid cleaned” using nitric acid solutions.

WARNING

THIS ACID CLEANING PROCEDURE INVOLVES THE USE OF HIGHLY CORROSIVE ACID SOLUTIONS. IT SHOULD ONLY BE COMPLETED BY TRAINED PERSONNEL USING PROTECTIVE EYEWEAR AND GLOVES. IF THERE IS ANY DOUBT ABOUT YOUR ABILITY TO SAFELY ACCOMPLISH THIS PROCEDURE, RETURN THE SENSOR TO BADGER METER FOR FACTORY CLEANING!

To acid clean the electrode assembly, remove the electrolyte chamber from the sensor so that the three (cathode, counter, reference) electrodes are exposed. Then follow the procedure below:

1. Place a small amount of 50% nitric acid solution in a beaker. Put in just enough so that the platinum cathode and counter electrodes can be submerged without any contact with the silver coil.
2. Allow the sensor to soak in this acid solution for 2 minutes. Remove the sensor body and rinse the platinum electrodes thoroughly with distilled water. Discard the nitric acid safely and according to all environmental regulations.
3. Fill the beaker with distilled water to the level sufficient to submerge both the tip and the silver coil. Do not allow the connector at the back of the sensor to be submerged. Allow the electrodes to soak in distilled water for 30 minutes.
4. Put a new membrane and fresh electrolyte in the electrolyte chamber and reassemble the sensor. Connect to the H_2O_2 monitor electronics and allow the sensor to stabilize for at least 24 hours. The sensor can be placed in the flowcell with hydrogen peroxide-containing water running through it during stabilization. However, the readings are not be useful for 24 hours.

Flowcell Maintenance

The maintenance on the flowcell is simple cleaning. The flowcell is clear to make examination of the condition of the sensor easier without interfering with operations. The flowcell may be cleaned by wiping or by washing with detergents or dilute acids. Do not try to clean with solvents as the acrylic may craze or crack.

Change the O-ring in the flowcell yearly or if any damage is observed. If insertion of the sensor into the flowcell becomes difficult, use silicon grease to lubricate the O-rings that hold the sensor in place. Use only enough grease to provide surface lubrication. Excess grease could foul the sensor membrane.

TROUBLESHOOTING

General

The information included in this section is intended to be used in an attempt to quickly resolve an operational problem with the system. During any troubleshooting process, it saves the most time if the operator can first determine if the problem is related to the analyzer, sensor or some external source. Therefore, this section is organized from the approach of excluding any likely external sources, isolating the analyzer and finally isolating the sensor. If these procedures still do not resolve the operational problems, any results the operator may have noted here are helpful when discussing the problem with the factory technical support group.

External Sources of Problems

To begin this process, review the connections of the system to all external connections.

1. Verify the analyzer is earth grounded. For all configurations of the analyzer, an earth ground connection **MUST** be present for the shielding systems in the electronics to be active. Grounded conduit provides no earth connection to the plastic enclosure, so an earth ground wiring connection must be made at the power input terminal strip. Verify metal shield is present over incoming power connections. This shield is for safety purposes, but also blocks electrical spikes from relay and power wiring.
2. Verify the proper power input is present (5...17V DC).
3. Do not run sensor cables or analog output wiring in the same conduits as power wiring. If low voltage signal cables must come near power wiring, cross them at 90° to minimize coupling.
4. If rigid conduit has been run directly to the Q45 enclosure, check for signs that moisture has followed conduit into the enclosure.
5. Check for ground loops. Although the membrane sensor is electrically isolated from the process water, high frequency sources of electrical noise may still cause erratic behavior in extreme conditions. If readings are very erratic after wiring has been checked, check for a possible AC ground loop by temporarily disconnecting feed and drain lines from the flowcell while there is still water on the inside. The reading should be initially stable and then fall very slowly in a smooth fashion as peroxide is depleted in the static sample.
6. Carefully examine any junction box connections for loose wiring or bad wire stripping. If possible, connect the sensor directly to the analyzer for testing.
7. Check sensor membrane for fouling. Look closely for signs of grease or oil which may be present. Replace membrane and electrolyte, allow to stabilize and re-check. The procedure in [“Sensor Assembly” on page 19](#) must be followed when replacing the membrane.

Analyzer Tests

1. Disconnect power and completely disconnect all output wiring coming from the analyzer. Remove sensor wiring, relay wiring and analog output wiring. Re-apply power to the analyzer.
2. Using the *Simulate* feature, check analog outputs and relays with a DVM.
3. Check cell drive circuit. Place a wire short between terminals WHITE and BLUE. With a digital voltmeter (DVM), measure the voltage between terminals ORANGE and BLUE on the back of the monitor to verify that the millivolt value is actually –400 mV.
4. Check TC drive circuit. Place a wire-short between the GREEN and BLACK terminals. With a DVM, measure the voltage between terminals BLACK and RED to verify the TC drive voltage of about 4.8...5.1V DC open circuit. Remove DVM completely and connect a 100 Ohms resistor from the BLACK to RED terminals. The temperature reading should display approximately 0° C and the H₂O₂ reading should display approximately 0 ppm.

Display Messages

The Q45 Series instruments provide a number of diagnostic messages which indicate problems during normal operation and calibration. These messages appear as prompts on the secondary line of the display or as items on the *Fault List*.

Display Messages

Message	Description	Possible Correction
Max is 200	Entry failed, maximum user value allowed is 200.	Reduce value to ≤ 200 .
Min is 20	Entry failed, minimum value allowed is 20.	Increase value to ≥ 20 .
Cal Unstable	Calibration problem, data too unstable to calibrate. Icons do not stop flashing if data is too unstable. User can bypass by pressing ENTER .	Clean sensor, get fresh cal solutions, allow temperature and conductivity readings to fully stabilize, do not handle sensor or cable during calibration.
Out of Range	Input value is outside selected range of the specific list item being configured.	Check manual for limits of the function to be configured.
Locked!	Transmitter security setting is locked.	Enter security code to allow modifications to settings.
Unlocked!	Transmitter security has just been unlocked.	Displayed just after security code has been entered.
Offset High	The sensor zero offset point is out of the acceptable range of $-100 \dots 100$ nA.	Check wiring connections to sensor. Allow sensor to operate powered a minimum of 12 hours prior to first zero cal.
Sensor High	The raw signal from the sensor is too high and out of instrument range.	Check wiring connections to sensor.
Sensor Low	The raw signal from the sensor is too low.	Check wiring connections to sensor.
H ₂ O ₂ High	The peroxide reading is greater than the maximum of the user-selected range.	The peroxide reading is over operating limits. Set measuring range to the next highest level.
Temp High	The temperature reading is $> 55^{\circ}\text{C}$.	The temperature reading is over operating limits. Check wiring and expected temp level. Perform RTD test as described in sensor manual. Recalibrate sensor temperature element if necessary.
Temp Low	The temperature reading is $< -10^{\circ}\text{C}$.	Same as "Temp High" above.
TC Error	TC may be open or shorted.	Check sensor wiring and perform RTD test as described in sensor manual. Check the junction box connections.
H ₂ O ₂ Cal Fail	Failure of <i>H₂O₂ Calibration</i> . <i>FAIL</i> icon does not extinguish until successful calibration has been performed or 30 minutes passes with no keys being pressed.	Clean sensor, redo zero and span calibration. If still failure, sensor slope may be less than 25% or greater than 500%. Perform sensor tests as described in " Sensor Tests " on page 36. Replace sensor if there is still failure.
TC Cal Fail	Failure of <i>Temperature Calibration</i> . <i>FAIL</i> icon does not extinguish until successful calibration has been performed or 30 minutes passes with no keys being pressed.	Clean sensor, check cal solution temperature and repeat sensor temp calibration. TC calibration function only allows adjustments of $\pm 6^{\circ}\text{C}$. If still failure, perform sensor tests as described in " Sensor Tests " on page 36. Replace sensor if still failure.
EPROM Fail	Internal nonvolatile memory failure.	System failure, consult factory.
Checksum Fail	Internal software storage error.	System failure, consult factory.
Display Fail	Internal display driver fail.	System failure, consult factory.
Range Cal Fail	Failure of factory <i>Temperature Calibration</i> .	Consult factory.

Sensor Tests

1. Check the membrane condition. A membrane that is not stretched smoothly across the tip of the sensor causes unstable measurements. If necessary, change membrane and electrolyte.
2. Residual H₂O₂ sensors can be tested with a digital voltmeter (DVM) to determine if a major sensor problem exists. Follow the steps below to verify sensor integrity:
 - a. Disconnect the six sensor wires from the back of the H₂O₂ monitor. Those wires are color coded WHITE, BROWN, RED, ORANGE, BLACK and GREEN.
NOTE: The BROWN wire may be replaced with an ORANGE wire in some cables.
 - b. Remove the electrolyte chamber from the sensor and dry the electrodes with a paper towel.
 - c. Connect a DVM between the WHITE and ORANGE wires. Reading resistance, you should find an open circuit value of infinite resistance. Repeat this test between WHITE and BLUE wires. There must be no measurable resistance at all between these wires. Any resistance at all indicates either water in the cable connector or the breakdown in an electrode seal.
 - d. Connect a DVM between the RED and WHITE wires. The RED wire is part of the RTD circuit and the WHITE wire is part of the measuring cell. There should be no connection. Reading resistance, you should find an open circuit value of infinite resistance. Any resistance at all indicates either water in the cable connector or the breakdown in an electrode seal.
 - e. Connect the DVM between the RED and BLACK wires. These are the RTD leads, and you should find a resistance value that depends on the temperature. The table below lists the resistance values for various temperatures. Reading resistance between the RED and GREEN wires should give exactly the same values as between RED and BLACK.

Temperature	Resistance
0° C	100.0 Ω
5° C	101.9 Ω
10° C	103.9 Ω
15° C	105.8 Ω
20° C	107.8 Ω
25° C	109.7 Ω
30° C	111.7 Ω
35° C	113.6 Ω
40° C	115.5 Ω
45° C	117.5 Ω
50° C	119.4 Ω

If you suspect that water has gotten into a cable connection on a flow type sensor or into the plug connection of a submersible sensor, disconnect the cable and allow the parts of the sensor to sit in a warm place for 24 hours. If water in the connector is the problem, it should dry out sufficiently to allow normal sensor operation. However, steps 4 and 5 above has to be repeated after drying to see if the problem is gone.

3. Acid clean the sensor electrodes in accordance with the procedure "[Sensor Acid Cleaning](#)" on page 33.

SPARE PARTS

Part No.	Description
Spare Electronics	
**	Q45-84 Dissolved H ₂ O ₂ , External Pwr, (5...17V DC)
03-0342	Q45-84 Front Lid Assy
03-0361	External Pwr, PCB Assy
Spare Sensors	
00-0725	Dissolved H ₂ O ₂ Sensor, Flow Type
02-0067	Sensing Element Body, (for part number 00-0725)
Spare Sensor Components	
03-0029	Sensor Interconnect Cable with Connector, 25 ft
45-0007	Electrolyte Chamber
45-0321	Membrane Holder, PVC
05-0027*	Membranes, pkg. of 10
05-0004*	Spare Parts Kit, Screw & O-ring
09-0023*	Electrolyte, 4 oz (120 cc)
Spare Flowcells	
00-0043	Constant-Head Flowcell Assembly with Mounting Plate
00-1522	Sealed Acrylic Flowcell with Mounting Plate
42-0014	Flowcell O-ring (each)
Miscellaneous Components	
07-0100	Junction Box
31-0038	Interconnect Cable for Junction Box to Monitor Wiring
03-0371	Fixed Flow Regulator Assy

NOTE: Instrument is supplied with sufficient spare parts for 6...12 months of operation. For 2 year spare parts inventory, 3 each of the items marked with an asterisk are required.

** Consult factory for item numbers of replacement electronic assembly.

Lock/Unlock Code: 1456

INTENTIONAL BLANK PAGE

INTENTIONAL BLANK PAGE

