

High Pressure and Severe Service Valves

Type 1711



CONTENTS

Safety Precautions3

Unpacking & Inspection3

Description4

 Adjusting Spring Force4

 Orientation4

Removing the Valve for Service.5

Reassembling the Valve10

Parts Drawings15

SAFETY PRECAUTIONS

Neither Badger Meter® nor any Badger Meter affiliated entities assumes responsibility for the selection, use, and maintenance of any products. Responsibility for the selection, use and maintenance remains with the purchaser and end-user.

⚠ CAUTION

- **PERSONAL INJURY OR PROPERTY DAMAGE CAUSED BY SUDDEN RELEASE OF PRESSURE OR BURSTING OF PRESSURE RETAINING PARTS MAY RESULT IF SERVICE CONDITIONS EXCEED THOSE FOR WHICH THE PRODUCT WAS INTENDED. TO AVOID INJURY OR DAMAGE, PROVIDE RELIEF VALVE OVER PRESSURE PROTECTION AS REQUIRED BY GOVERNMENT OR ACCEPTED INDUSTRY CODES.**
- **ALWAYS WEAR PROTECTIVE GLOVES, CLOTHING, AND EYE WEAR WHEN PERFORMING ANY INSTALLATION OPERATIONS TO AVOID PERSONAL INJURIES.**
- **THIS VALVE IS INTENDED FOR A SPECIFIC RANGE OF TEMPERATURES AND PRESSURES. APPLICATION OF DIFFERENT TEMPERATURES THAN THOSE SPECIFIED COULD RESULT IN PARTS DAMAGE, VALVE MALFUNCTION, OR LOSS OF CONTROL OF THE PROCESS.**
- **DO NOT REMOVE THE ACTUATOR FROM THE VALVE WHILE THE VALVE IS STILL PRESSURIZED.**
- **DISCONNECT ANY OPERATING LINES PROVIDING AIR PRESSURE, ELECTRIC POWER, OR CONTROL SIGNAL TO THE ACTUATOR OR ACCESSORIES.**
- **USE BYPASS VALVES OR COMPLETELY SHUT OFF THE PROCESS LINE TO ISOLATE THE VALVE FROM PROCESS PRESSURE. RELIEVE PROCESS PRESSURE AND DRAIN PROCESS MEDIA FROM BOTH SIDES OF THE VALVE.**
- **CONSULT A TRAINED SAFETY ENGINEER FOR ANY ADDITIONAL MEASURES THAT MUST BE TAKEN TO PROTECT AGAINST PROCESS MEDIA.**

UNPACKING & INSPECTION

Upon opening the shipping container, visually inspect the product and applicable accessories for any physical damage such as scratches, loose or broken parts, or any other sign of damage that may have occurred during shipment.

NOTE: If damage is found, request an inspection by the carrier's agent within 48 hours of delivery and file a claim with the carrier. A claim for equipment damage in transit is the sole responsibility of the purchaser.

DESCRIPTION

The Type 1711 valve is supplied with a 35 sq. in. actuator, which can be either Air-to-Open (ATO) or Air-to-Close (ATC). Due to the weight of the actuator, external support is required for the valve. The actuator must be supported with external brackets and must be mounted to a suitable surface for total valve weight support.

Adjusting Spring Force

If the unit is ATO, the instrument signal (3...15 psi, 6...30 psi) should be piped into the *lower* pressure case using a 1/4" NPT fitting. To seal the connection, use pipe dope or PTFE paste on the fitting threads. The upper case will have a black plastic vent plug installed. It is best to leave it in place.

Although spring loading is normally factory adjusted, should spring force need to be increased:

1. Calculate the required amount of preload by multiplying the innervalue's orifice area by the shutoff pressure and dividing by 34. This indicates the *air preload setting*.
Example: 1000 psi shutoff \times 0.197 sq. in. = 5.8 (rounded up to 6.0)
2. To adjust, simply apply 6 psi to the lower pressure case. The stem will rise (be sure it is safe for the valve to open by shutting off upstream pressure).
3. Using a backup wrench on the flats on the actuator stem, loosen the adjuster lock nut.
4. Rotate the adjuster counterclockwise until the innervalue seats. Then, tighten the stem lock nut.

The preload is now set.

If the unit is ATC, the instrument signal should be piped into the *upper* case. The lower case will have the vent fitting. If the valve is not closing against incoming pressure (and the valve is equipped with a positioner), simply increase the supply pressure to the positioner until shutoff is achieved.

In the ATC configuration, the springs simply open the valve and do not assist in valve closure.

Although the actuator can provide long service life without maintenance, occasionally repairs are necessary. In that case, contact the factory and we will supply you with actuator disassembly instructions.

The size 35 actuator is field-reversible. If you need to reverse the action of your actuator, contact the factory for instructions.

If the unit is factory equipped with a positioner or other accessories, it is normal procedure to include any instructions that come with the accessories in the plastic bag with the valve.

- DO NOT rotate the actuator on the bonnet if the innervalue is seated. The innervalue will be damaged.
- DO brace the actuator if using in a vibration or shock situation.
- DO NOT expect the valve (with throttling innervalue) to shut off completely. Normal innervalue leakage class is ANSI Class IV.

Orientation

Standard orientation is with the valve stem and actuator in a vertical plane and the process fluid entering the valve from the bottom and discharging through the side in a horizontal plane.

The valve body must be installed such that the outlet connection flow is horizontal or slightly tilted down, away from the valve body. Failure to properly install the valve will result in improper draining.


Other orientations may be chosen if internal drainage is not critical.

WARNING

PERSONAL INJURY OR PROPERTY DAMAGE MAY OCCUR IF THE VALVE IS NOT PROPERLY MOUNTED AND SUPPORTED.

REMOVING THE VALVE FOR SERVICE


1. In order to service the valve, first make sure all pressure (both upstream and downstream of the valve) is relieved.
2. Applicable for Air-to-Open. Using a manually operated regulator applied to the actuator or positioner, stroke the valve upward to approximately 75% travel. This lifts the innervalue off the seat, to prevent damage to the innervalue seating
3. Place a wrench on the adjuster to keep it from turning. With a wrench on the innervalue lock nut, loosen the lock nut, and unthread the innervalue stem out of the adjuster.
4. Loosen and remove, the yoke lock nut.
5. Lift the actuator off the valve body/bonnet assembly.



6. Clamp the valve body in a heavy duty vise.

NOTE: Position the valve body in the vise with the ends of the body touching the vise jaws, as indicated by the black arrows on the sketch. Do not clamp on the sides of the body or the hex ends of the body, unless the body has welded-in fittings or pipe. In that case, it is ok to clamp on the hex ends.

7. Using a large adjustable wrench (Crescent® type), loosen and remove the Union Nut. DO NOT use a pipe wrench.



8. Before loosening the packing gland, pull the innervalue up to full travel.

9. Carefully, with leather- or rubber-gloved hand, pull the bonnet straight up.


NOTE: Slight rotation of the bonnet might be required to break loose the gasket as it may be slightly stuck to the graphite gasket.

To preclude galling:

- Do not pry or cock bonnet in the body guide.
- Do not use pliers or pipe wrench to loosen.

If the bonnet does not loosen by hand, wrap the bonnet (in the area indicated by the double-arrows) with thick rubber or leather and use a pair of large channel-lock pliers to grasp and twist the bonnet.

NOTE: Once loosened by this method, remove the bonnet by hand.




NOTE: The 1711 series of valves uses 2 gaskets per valve. If only one gasket is used, proper compression and seal will not be made.

Although new gaskets are recommended, under some conditions, the old gasket might serve well.

10. Check to see if the graphite gasket surface is damaged. If the gasket material is stuck to the bonnet, or if torn, replace with new gaskets.


If replacing gaskets, use a soft metal or plastic tool to remove all the graphite from the bonnet and body cavity. Then, using a brass or SST brush, with solvent, remove remaining pieces of the gasket and dry.




11. Remove the seat from the body and clean the body of debris. If you already have new components, it is normally best to leave the body in the vise. To remove the seat, use a deep, thin-walled socket in the following sizes:

- 1/2 in. Valve: 5/8 in. hex
- 3/4 in. Valve: 3/4 in. hex
- 1 in. Valve: 15/16 in. hex

If replacing the innervalue and the old innervalue is still usable, place the old innervalue set in the tube and re-mark the proper information on the tube.



12. Loosen the packing gland and pull the innervalue out the bottom of the bonnet.




13. Remove the packing gland.

14. Using a wooden or plastic dowel slightly smaller than 1/2 in., insert it into the bottom of the bonnet as shown.


15. Holding the bonnet in one hand, place the dowel on a hard surface and push the packing and SST ring out the top of the bonnet.

16. Inspect the bonnet for damage and clean it in solvent.



REASSEMBLING THE VALVE


1. Using an acceptable grease, lightly coat the stem and the guide area of the NEW innervalue and insert it up through the bonnet.
2. Place these items onto the stem, in this order:
 - a. The SST bottom ring (it is uni-directional)
 - b. The bottom TFE adapter, cone up
 - c. Three V-rings, cup down/cone up
 - d. The top TFE follower, cup down/flat end up
3. Lubricate the threads of the gland. Using the packing gland as a pusher, push the packing down into the bonnet until the threads of the gland make contact with the threads in the bonnet. Then thread the gland into the bonnet until hand tight.
4. Tighten the gland a little at a time until you feel packing friction (light dragging) on the innervalue stem as you stroke it up and down by hand, then stop. Further tightening or adjustment should be made after the valve is assembled.




5. Remove the new seat from the shipping tube and carefully start it into the body. Once started, use the socket to tighten the seat in the body to the following torque values:

- 1/2 in. Valve > 30...35 lb-ft
- 3/4 in. Valve > 35...40 lb-ft
- 1 in. Valve > 40...45 lb-ft

Although new seats come with graphite lubricant painted on the threads, a light amount of pipe dope can be used on the threads and seating angle, if desired.



6. Place 2 new graphite gaskets into the gasket cavity of the bonnet. Be careful, they are brittle.
7. Lubricate the guide areas of the bonnet.
8. With the innervalue still pulled up, carefully lower the bonnet into the body until it seats against the gasket. Rotate the bonnet a very slight amount to make sure it is "squared" in the body and onto the gasket.




9. Lubricate the threads of the union nut and thread it onto the body. Torque to the following:


- 1/2 in. Valves > 300 lb-ft
- 3/4 in. Valves > 300 lb-ft
- 1 in. Valves > 500 lb-ft

NOTE: The valve design is rated for the maximum pressure indicated in the Product Data Sheet, only if the union nut is properly installed. If a torque wrench is not available, you can tighten the nut with an adjustable wrench and test for leaks. Re-tighten if leakage occurs. Perform leak testing of the gasket at a pressure slightly above the process pressure but DO NOT exceed the pressure ratings shown in the Product Data Sheet.

10. With the stem still in the up position, thread the 1/4-28 innervalve jam nut onto the innervalve (to the bottom of the threads).



11. With air on the ATO actuator, carefully set the actuator onto the bonnet (be sure to slip the yoke lock nut over the stem).
12. Orient the actuator and tighten the yoke lock nut.
13. Thread the innervalue stem into the adjuster until it stops. DO NOT use the pliers on the stem. Using a back-up wrench on the adjuster, tighten the innervalue lock nut (jam nut).
14. Re-connect any accessories and make necessary adjustments.
15. Test packing for leaks, tightening only enough to stop leakage. Overtightening can damage packing.
16. Check that stroke is 9/16 in. (14 mm).



PARTS DRAWINGS

DWG NO.	ISSUE	ISS	CHANGE	BY	DATE	UNLESS OTHERWISE SPECIFIED DIMENSIONS FOR REFERENCE ONLY LENGTH UNITS ARE INCHES	ALL PROPRIETARY RIGHTS IN THE SUBJECT MATTER SHOWN ON THIS DRAWING ARE THE EXCLUSIVE PROPERTY OF BADGER METER INCORPORATED.
CD-951709	01.03	01.02	REDRAW, RCV #120	GAP	01-27-99		
		01.03	CL. 8L ADD TYPE 1711, REV. 2 526896-005 526897	GAP	05-11-99		

NOTES:

1.) TRIM ASSEMBLY P/N _____
SIZE: _____ CV: _____ CHAR: _____

2.) NOMINAL STROKE: .562

3.) RECOMMENDED SPARE PARTS ARE:
ITEMS 8 (PACKING SET) & 5 (GASKETS)
OPTIONAL SPARE PARTS ARE:
ITEMS 3 (TRIM SET)

4.) WHEN ORDERING SPARE OR REPLACEMENT
PARTS, PROVIDE FACTORY THE VALVE
ASSEMBLY SERIAL NUMBER FROM THE
NAMEPLATE ON THE ACTUATOR.

PARTS & MATERIAL LIST

QUANTITIES ARE FOR ONE (1) UNIT ONLY

ITEM NO.	PART NO.	QTY	DESCRIPTION	MATERIAL
1	526897-00	1	BODY	
2	525949-00	1	BONNET	
3a	SEE NOTE 1	1	INNERVALVE	
3b	SEE NOTE 1	1	SEAT	
4	525944-0001	1	LOCKNUT	300 SERIES SST
5	512711-0001	2	GASKET	GRAFOIL
6	525951-00	1	ADAPTOR	
7	526896-00	1	UNION NUT	
8	543242-00	1	PACKING SET	
9	525950-00	1	GLAND	

CERTIFIED FOR: _____ P.O.: _____ LOCATION: _____ SERIAL NO.: _____ TAG NUMBER: _____ PREPARED BY: _____ DATE: _____	<p>BADGER METER RESEARCH CONTROL VALVES</p> <p>1/2" GLOBE BODY/BONNET ASS'Y UNION GASKET JOINT, .312 GUIDED TRIM- TYPE 1711</p> <table style="width: 100%; font-size: small;"> <tr> <td>SIZE</td> <td>SCALE</td> <td>DWG. NO.</td> <td>ISSUE</td> </tr> <tr> <td>A</td> <td>3/4</td> <td>CD-951709</td> <td>01.03</td> </tr> </table>	SIZE	SCALE	DWG. NO.	ISSUE	A	3/4	CD-951709	01.03
SIZE	SCALE	DWG. NO.	ISSUE						
A	3/4	CD-951709	01.03						

DWG NO. CD-951710	ISSUE 01.03	ISS 01.02 REDRAW, RCV #120 01.03 CL. & ADD TYPE 1711, ITEM 7 526896 WAS 526901	CHANGE	BY CAP	DATE 01-27-99 05-11-99	UNLESS OTHERWISE SPECIFIED DIMENSIONS FOR REFERENCE ONLY LENGTH UNITS ARE INCHES	ALL PROPRIETARY RIGHTS IN THE SUBJECT MATTER SHOWN ON THIS DRAWING ARE THE EXCLUSIVE PROPERTY OF BADGER METER INCORPORATED.
-----------------------------	-----------------------	--	--------	------------------	--	--	---

NOTES:

1.) TRIM ASSEMBLY P/N _____
SIZE: _____ CV: _____ CHAR: _____

2.) NOMINAL STROKE: .562

3.) RECOMMENDED SPARE PARTS ARE:
ITEMS 8 (PACKING SET) & 5 (GASKETS)
OPTIONAL SPARE PARTS ARE:
ITEMS 3 (TRIM SET)

4.) WHEN ORDERING SPARE OR REPLACEMENT
PARTS, PROVIDE FACTORY THE VALVE
ASSEMBLY SERIAL NUMBER FROM THE
NAMEPLATE ON THE ACTUATOR.

PARTS & MATERIAL LIST				
QUANTITIES ARE FOR ONE (1) UNIT ONLY				
ITEM NO.	PART NO.	QTY	DESCRIPTION	MATERIAL
1	526907-00	1	BODY	
2	525949-00	1	BONNET	
3a	SEE NOTE 1	1	INNERVALVE	
3b	SEE NOTE 1	1	SEAT	
4	525944-0001	1	LOCKNUT	300 SERIES SST
5	512711-0001	2	GASKET	GRAFOIL
6	525951-00	1	ADAPTOR	
7	526896-00	1	UNION NUT	
8	543242-0001	1	PACKING SET	
9	525950-00	1	GLAND	

(.250-28 UNF 2A)

Ø1.125

3.08

1.19

3.38

3/4" NPT

ARCH →

<p>CERTIFIED FOR: _____</p> <p>P.O.: _____</p> <p>LOCATION: _____</p> <p>SERIAL NO.: _____</p> <p>TAG NUMBER: _____</p> <p>PREPARED BY: _____ DATE: _____</p>	<div style="text-align: center;">BADGER METER RESEARCH CONTROL VALVES</div> <div style="text-align: center;">3/4" GLOBE BODY/BONNET ASS'Y UNION GASKET JOINT, .312 GUIDED TRIM- TYPE 1711</div> <table border="1" style="width: 100%; border-collapse: collapse;"><tr><td style="width: 15%;">SIZE A</td><td style="width: 15%;">SCALE 3/4</td><td style="width: 25%;">DWG. NO. CD-951710</td><td style="width: 45%;">ISSUE 01.03</td></tr></table>	SIZE A	SCALE 3/4	DWG. NO. CD-951710	ISSUE 01.03
SIZE A	SCALE 3/4	DWG. NO. CD-951710	ISSUE 01.03		

DWG NO. CD-951711	ISSUE 01.03	ISS 01.02	CHANGE REDRAW, RCV #120	BY GAP	DATE 01-27-99	UNLESS OTHERWISE SPECIFIED DIMENSIONS FOR REFERENCE ONLY LENGTH UNITS ARE INCHES	ALL PROPRIETARY RIGHTS IN THE SUBJECT MATTER SHOWN ON THIS DRAWING ARE THE EXCLUSIVE PROPERTY OF BADGER METER INCORPORATED.
		01.03 CL III, ADD 1/2", 3/4"		GAP 04-14-99			


DIMENSIONS			
Ps	A	B	C
1/2"	2.75	1.00	2.89
3/4"	3.38	1.19	3.08
1"	4.00	1.50	3.72


PARTS & MATERIAL LIST						
QUANTITIES ARE FOR ONE (1) UNIT ONLY						
ITEM NO	1/2" PART NO	3/4" PART NO	1" PART NO	QTY	DESCRIPTION	MATERIAL
1	526897-00	526907-00	526904-00	1	BODY	
2	525949-00	525949-00	526152-00	1	BONNET	
3a	SEE NOTE 1	SEE NOTE 1	SEE NOTE 1	1	INNERVALVE	
3b	SEE NOTE 1	SEE NOTE 1	SEE NOTE 1	1	STEAM	
4	525944-00	525944-00	525944-00	1	LOCKNUT	
5	512711-0001	512711-0001	512702-0001	2	GASKET	GRAFOIL
6	525951-00	525951-00	525951-00	1	ADAPTOR PKG	
7	526896-00	526896-00	526903-00	1	UNION NUT	
8	543242-00	543242-00	543242-00	1	PACKING SET	
9	525950-00	525950-00	525950-00	1	GLAND	
10a	500458-0024	500458-0024	500458-0024	1	LUBRICANT	N/A

NOTES:

- 1.) TRIM ASSEMBLY P/N _____
SIZE: _____ CV: _____ CHAR: _____
- 2.) NOMINAL STROKE: .562
- 3.) RECOMMENDED SPARE PARTS ARE:
ITEMS 8 (PACKING SET) & 5 (GASKETS)
OPTIONAL SPARE PARTS ARE:
ITEMS 3 (TRIM SET)
- 4.) WHEN ORDERING SPARE OR REPLACEMENT PARTS, PROVIDE FACTORY THE VALVE ASSEMBLY SERIAL NUMBER FROM THE NAMEPLATE ON THE ACTUATOR.

CERTIFIED FOR: _____ P.O.: _____ LOCATION: _____ SERIAL NO.: _____ TAG NUMBER: _____ PREPARED BY: _____ DATE: _____	BADGER METER RESEARCH CONTROL VALVES 1/2", 3/4", 1" HP CAST GLOBE BODY UNION GASKET JOINT, STANDARD BONNET, .312 GUIDED TRIM, CV PACKING <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%;">SIZE A</td> <td style="width: 15%;">SCALE 5/8</td> <td style="width: 25%;">DWG. NO. CD-951711</td> <td style="width: 45%;">ISSUE 01.03</td> </tr> </table>	SIZE A	SCALE 5/8	DWG. NO. CD-951711	ISSUE 01.03
SIZE A	SCALE 5/8	DWG. NO. CD-951711	ISSUE 01.03		





Control. Manage. Optimize.

Research Control is a registered trademark of Badger Meter, Inc. Other trademarks appearing in this document are the property of their respective entities. Due to continuous research, product improvements and enhancements, Badger Meter reserves the right to change product or system specifications without notice, except to the extent an outstanding contractual obligation exists. © 2021 Badger Meter, Inc. All rights reserved.

www.badgermeter.com