

FOR ELECTRONIC REGISTER PART NUMBER 66300 AND SERVICE KIT 65518 ONLY

| | |
|---------------------------|------------------------------------------------------------------------------------------------------|
| Programming Switch | Located on the underside of the module. |
| Total Button | Press when in <i>normal</i> operation to display the total quantity of fluid dispensed by the meter. |
| | Press when in the <i>programming</i> mode to select an item to be changed. |
| Reset Button | Press <i>momentarily</i> to clear the display. |
| | Press when in the <i>programming</i> mode to change a flashing object on the display. |

TO CHANGE UNITS OF MEASURE

1. Remove the electronic register module to gain access to the PROGRAMMING switch on the bottom of the module.
2. Press and release the **PROGRAMMING** switch to access the programming mode. The active unit of measure symbol will flash when you have entered the programming mode.
3. Toggle **RESET** until the desired unit of measure symbol appears.
4. Press and release the **PROGRAMMING** switch to exit the programming mode.

The display will flash three times and then go blank to indicate the changes have been saved.

NOTE: Changing any unit of measure will reset the totalizer to zero.

TO PROGRAM THE SCALE FACTOR

When replacing an old style electronic register, the correction factor must be converted using the conversion chart on page 2. The correction factor is marked on the meter under the register.

The new register (part number 66300) has the added feature of saving the correction factor in non-volatile memory. If the battery is replaced, the correction factor will no longer need to be reprogrammed into the register.

1. Remove the electronic register module to gain access to the PROGRAMMING switch on the bottom of the module.
2. Press and release the **PROGRAMMING** switch to access the programming mode. The active unit of measure symbol will flash when you have entered the programming mode.
3. Press **TOTAL** to advance to the first digit of the correction factor.
4. The selected digit will blink. Press **RESET** to change the value.
5. Press **TOTAL** to move to the next digit.
6. Continue this process until the correction factor has been entered.
7. Press and release the **PROGRAMMING** switch to exit the programming mode.

The display will flash three times and then go blank to indicate the changes have been saved.

MODEL OG CONVERSION CHART

Old Register to New Register

| Oil | |
|--------------------|----------|
| PN 62580 and 64870 | PN 66300 |
| 3.496 | 1.008 |
| 3.481 | 1.004 |
| 3.460 | 1.000 |
| 3.438 | 0.994 |
| 3.423 | 0.986 |

| Engine Coolant | |
|--------------------|----------|
| PN 62580 and 64870 | PN 66300 |
| 3.649 | 1.052 |
| 3.634 | 1.048 |
| 3.612 | 1.044 |
| 3.589 | 1.038 |
| 3.554 | 1.029 |

| Wiper Fluid | |
|--------------------|----------|
| PN 62580 and 64870 | PN 66300 |
| 3.731 | 1.076 |
| 3.715 | 1.072 |
| 3.693 | 1.067 |
| 3.669 | 1.061 |
| 3.634 | 1.052 |

NOTE:Electronic registers 62580-XXX and 64870-XXX are replaced with electronic register 66300-XXX..

Control. Manage. Optimize.

Trademarks appearing in this document are the property of their respective entities. Due to continuous research, product improvements and enhancements, Badger Meter reserves the right to change product or system specifications without notice, except to the extent an outstanding contractual obligation exists. © 2022 Badger Meter, Inc. All rights reserved.

www.badgermeter.com